





































Original	Sustituto
 Power	 Power
 Tv/AV	 AV
 1	 1
 2	 2
 3	 3
 5	 5
 4	 4
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Mute	 Mute
 Q.View	 Options
 List	 List
 Menu	 Menu
 OK	 Ok

Original	Sustituto
 ARC	 Media
 PR+	 Ch +
 Up	 Up
 Down	 Down
 PR-	 Ch -
 Vol+	 Vol +
 Right	 Right
 Left	 Left
 Vol-	 Vol -
 Play	 Play
 Stop	 Stop
 >>/FF	 I<<
 <</REW	 <<
 Rec	 Rec
 Pause	 Pause
 Power	 Shift + Power
 SP/LP	 TV/R



