







































































Original	Sustituto	Original	Sustituto
 Power	 Power	 Stop / Reveal	 Stop
 Mute	 Mute	 << / Hold	 <<
 Red	 A	 >> / Subpage	 >>
 Green	 B	 I<< / Size	 I<<
 Yellow	 C	 >>I / Cancel	 >>I
 Blue	 D	 Info	 Info
 EPG	 GUIDE	 Input	 AV
 Repeat	 D. Menu	 Up	 Up
 Zoom	 Eject	 Left	 Left
 Goto	 3D	 OK	 Ok
 Sub-T	 Subt	 Right	 Right
 Audio	 Dual	 Down	 Down
 Sleep	 Sleep	 Menu	 Menu
 TV/Radio	 TV/R	 Exit	 Exit
 Text	 Text	 Vol+	 Vol +
 Play / Index	 Play	 Vol-	 Vol -
 Pause / Mix	 Pause	 P-Mode	 Format





Original	Sustituto
S-Mode	List
CH+	Ch +
CH-	Ch -
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
-/--	Shift + Guide
0	0
Recall	Back
Fav	Pre Ch
Fav+	Smart

Original	Sustituto
Fav-	Media

