







































































Original	Sustituto	Original	Sustituto
	Mute		Mute / Dimmer
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	C		Setup / OPT /
	0		0
	Saturn		Display / Media
	Book		Picture / Format
	N9UF		Shift + 9
	Text		Text / Goto
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	V +		Vol+
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	P +		CH+ / Page+
	V -		Vol-
	Down		Down
	P -		CH- / Page-
	Back		Back / Return
	i		Info / Angle
	<<		<< / Tune-
	I<<		I<< / Preset-





Original	Sustituto
	Smart / List
	>> / Tune+
	>>I / Preset+
	Play / Slow
	Shift + Play /
	Rec / Rec Mode
	Stop / Hold
	Menu / Home

Original	Sustituto



Mandis

Mandis