

















Original	Sustituto
 Power	 Power
 TV	 Smart
 VCR/AUX	 Media
 Sleep	 Sleep
 Tv/AV	 AV
 Tuner/Band	 TV/R
 DVD/CD	 Pre Ch
 FL	 3D
 Play Mode-Mix	 Shift + Play
 Repeat	 Text
 Position	 Shift + Smart
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6

Original	Sustituto
 7	 7
 8	 8
 9	 9
 0	 0
 +10/-/-	 Guide
 Cancel	 Exit
 I<< Skip	 I<<
 Skip >>I	 >>I
 << Slow/Search	 <<
 Slow/Search >>	 >>
 Stop	 Stop
 Pause	 Pause
 Play	 Play
 Top Menu/Direct Navigator	 Shift + Menu
 Menu/Play List	 Menu
 Display	 Info
 Return	 Back





Original	Sustituto
	 Up
	 Down
	 Right
	 Left
	 Ok
	 Vol +
	 Vol -
	 Mute
	 Options
	 Subt
	 D. Menu
	 Red
	 Green
	 Yellow
	 List
	 Format
	 Eject

Original	Sustituto
	 Blue
	 Dual



