


























































Original	Sustituto	Original	Sustituto
Power ON/Off	 Power	Pr 2	 2
Vol Rs-/Effect	 Subt	Pr 3	 3
Sleep	 Sleep	Pr 4	 4
CD Random	 D. Menu	Pr 5	 5
Tape 2 Pre./eq	 Dual	Pr 6	 6
Repeat	 Text	Mode	 Options
Display	 Info	Pr 7	 7
CD/Theater	 TV/R	Pr 8	 8
Volume+	 Vol +	Program	 +  Shift + Sleep
CD Play	 Play	Pr 9	 9
CD Rewind	 I<<	Pr 0/10	 0
CD F.FWD	 >>I	Store/Center-	 Format
CD Pause	 Pause	Tape 1 Play	 Yellow
Tape 1 Hall/Ats	 3D	Tape 1 F.FWD	 Blue
Funct./Direct	 List	6 Ch/Geq	 +  Shift + 6
Volume-	 Vol -		
Pr 1	 1		



Original	Sustituto	Original	Sustituto
Power ON/Off	 Power	Pr 4	 4
Mute	 Mute	Phono/Scan	 Media
Tape 1 Stop	 +  Shift + Stop	Pr 5	 5
Tape 2 Pre./eq	 Smart	Tuner/Bypass	 TV/R
CD/Theater	 Text	Pr 6	 6
CD Rewind	 I<<	Pr 7	 7
Tape 1 Hall/Ats	 Format	Pr 8	 8
CD F.FWD	 >>I	Band	 Eject
CD Play	 Play	Fm Mode/Disc	 D. Menu
Funct./Direct	 List	Tape 1 Rew	 Green
Input/Source	 AV	Tape 1 Play	 Yellow
Volume+	 Vol +	Tape 1 F.FWD	 Blue
Volume-	 Vol -		
Pr 1	 1		
Stop	 Stop		
Pr 2	 2		
Pr 3	 3		



















Original	Sustituto	
Power ON/Off		Power
Mute		Mute
Every Pop		Red
Tape 1 Stop	 + 	Shift + Stop
Tape 1 Preset	 + 	Shift + List
Vol Rs-/Effect	 + 	Shift + Left
Preset Pause	 + 	Shift + Pause
Sleep		Sleep
Tape 2 Pre./eq	 + 	Shift + Media
Repeat		Text
Input/Source		AV
Display		Info
CD Random	 + 	Shift + Text
Vol Rs+/S.Mode	 + 	Shift + Right
Woofers/Speed		Subt
CD/Theater		List
Funct./Direct		Menu

Original	Sustituto	
Volume+		Vol +
Next/Prog+		Ch +
Volume-		Vol -
Tape 1 Hall/Ats	 + 	Shift + 3D
Mode		Options
Prev./Prog-		Ch -
Program	 + 	Shift + Sleep
CD Play		Play
Stop		Stop
Pr 1		1
Tape 2		Down
CD Rewind		l<<
Pr 2		2
Timer/A.Track	 + 	Shift + Dual
+10/Next Sv+v		Guide
CD F.FWD		>>l
Tape 2		Left



Original	Sustituto
Pr 3	 3
Disc 1 Eject	 +  Shift + 1
Disc 2	 +  Shift + 2
Classic Track	 Dual
Disc 3 Eject	 +  Shift + 3
Disc 4 Eject	 +  Shift + 4
Track-/Echo	 +  Shift + Ch -
Intro	 +  Shift + Info
Edit	 Format
X-Bass/Bgm	 Green
Phono/Scan	 Ok
Surround/Test	 +  Shift + Subt
Fm Mode/Disc	 D. Menu
Track+/Karaoke	 +  Shift + Ch +
Dimmer	 +  Shift + Mute
Mark/Delete	 Back
Tuner/Bypass	 Yellow

Original	Sustituto
Erase/Snooze	 +  Shift + Back
Disc 5	 +  Shift + 5
6 Ch/Geq	 6
Tape 1 Rew	 +  Shift + <<
Space/Default 3D	 3D
CD Pause	 Pause
Index+/Vol Ls+	 +  Shift + Up
Tape 1 F.FWD	 +  Shift + >>
Store/Center-	 Blue
Tape 1 Play	 +  Shift + Play
Search/Center	 +  Shift + TV/R
Clear	 Exit
Index-/Vol Ls-	 +  Shift + Down
ON/Off	 +  Shift + Power
Tape 1 Rec	 Rec
Eject	 Eject
Center	 TV/R



Original	Sustituto	Original	Sustituto
Band	 Smart		
Aux/Video	 +  Shift + AV		
Tape 2 REC./Jazz	 +  Shift + Rec		
Tape 2	 Up		
Tape 2 FF/AudioR	 Right		
Ubs/Check	 Media		
Tune/Vol SW-	 <<		
Tune/Vol SW+	 >>		

