





































































Original	Sustituto
 Power	 Power
 Source	 AV / Input / RDS
 Caption	 Subtitle / EQ
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 Eject / Surround
 PRE-CH	 0
 Auto Prog.	 Fav / Marker / PC
 FAV.CH	 TV/Radio /
	 Shift + Fav / Marker / PC

Original	Sustituto
 ADD/Del	 D.Menu / Top
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 CH+	 CH+ / Page+
 Vol-	 Vol-
 CH List	 Smart / List
 CH-	 CH- / Page-
 Menu	 Menu / Home
 MTS	 Display / Media
 Guide	 Guide / EPG / -/--
 Tools	 Setup / OPT /
 Up	 Up
 Info	 Info / Angle
 Left	 Left
 Enter	 OK
 Right	 Right
 Return	 Back / Return



