






































	Original	Sustituto	Original	Sustituto
	 Power	 Power	 Exit	 Exit
	 Mute	 Mute	 Up	 Up
	 1	 1	 Down	 Down
	 2	 2	 Right	 Right
	 3	 3	 Left	 Left
	 4	 4	 OK	 Ok
	 5	 5	 Vol+	 Vol +
	 6	 6	 Vol-	 Vol -
	 7	 7	 Sound	 Shift + Dual
	 8	 8	 PIC	 Options
	 9	 9	 CH+	 Ch +
	 0	 0	 CH-	 Ch -
	 Audio	 Dual	 Sleep	 Sleep
	 Recall	 Back	 Aspect	 3D
	 Tv-Menu	 Menu	 Freeze	 Shift + Media
	 Source	 AV	 Tv/Radio	 TV/R
	 CH.List	 List	 Text	 Text





Original	Sustituto
	Guide
	Pre Ch
	Info
	Red
	Green
	Yellow
	Blue
	Eject
	D. Menu
	Smart
	Shift + Info
	Shift + Subt
	Format
	Media
	Subt
	<<
	>>

Original	Sustituto
	I<<
	>>I
	Play
	Pause
	Stop
	Rec

