Mandis shop

Sony RMT-845

Original		Substitut	
TC RESET	TC Reset	CLEAR EXIT CANCEL	Exit / Cancel / Clear
DATA CODE	Data Code	LIST SMART	Smart / List
	Start/Stop		Power
SCAN	<I Scan/Slow	TUNE-	<< / Tune-
SLOW	Scan/Slow I>	TUNE+	>> / Tune+
T	T	CH PAGE +	CH+ / Page+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
PLAY	Play	SLOW	Play / Slow
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
W	W	CH PAGE −	CH- / Page-
STOP	Stop	HOLD	Stop / Hold
	Up		Up
MODE	Mode	FORMAT PICTURE	Picture / Format
	Left		Left
ENTER	Enter	OK	OK
	Right		Right

Original		Substitut	
DISPLAY	Display	MEDIA DISPLAY	Display / Media
	Down		Down

https://mandis.es/catalogo/Sony/10617-964-control-de-substitucion-Sony-RMT-845.html