Mandis shop

RCT200DV

Original		Substitut	
	Power		Power
OPEN / CLOSE	Open/Close	ZOOM	Eject
	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
AUDIO	Audio	SOUND DUAL	Dual
	(.....)	AD SUBT	Subt
	Movie	HOME SMART	Smart
MENU	Menu	TOP MENU MENU	Menu

Original		Substitut	
TITLE	Title	APP MEDIA	Media
	(¨¨¨¨)	SEARCH TV/R	TV/R
EXIT	Exit	CLEAR EXIT	Exit
	>>		>>
	<<		<<
OK	Play	PLAY MODE	Play
OK	OK	OK	Ok
	>		Right
	<		Left
	Up		Up
	Down		Down
	>>I		>>I
	I <<		I <<
	Stop		Stop
REPEAT	Repeat	REPEAT TEXT	Text
	Pause		Pause
INDEX	Index	DISC NAV LIST	List

https://mandis.tv/es/control-remoto-sustituto-RCT200DV