Original	Replacement	Original	Replacement
Power	Power	Exit	Exit
Mute	Mute	PR+	Ch +
1	1	PR-	Ch -
2	2	Vol +	Vol +
3	3	Vol -	Vol -
4	4	Up	Up
5	5	Down	Down
6	6	Right	Right
7	7	Left	Left
8	8	OK/List	Ok
9	9	↑	>>
0	0	↓	<<
Tv/Radio	TV/R	Pause	Pause
↩PR	Back	Red	Red
EPG	Guide	Green	Green
Menu	Menu	Yellow	Yellow
Info	Info	Blue	Blue

Original		Replacement		Original		Replacement	
AUDIO	Audio		Dual				
TXT	TXT	T	Text				
	[. . .]		Subt				
	Audio L/R		Smart				
	[+]		3D				
FAV	FAV		Pre Ch				
UHF	UHF	SC NA	Media				
PAL/NTSC	PAL/NTSC		Format				
TV/AV	Tv/AV		AV				

Original	Replacement	Original	Replacement
Power	Power	Exit	Exit
Mute	Mute	Up/ PR+	Up
1	1	Down/ PR-	Down
2	2	OK/ List	Ok
3	3	Right	Right
4	4	Left	Left
5	5	Vol +	Vol +
6	6	Vol -	Vol -
7	7	↑	Ch +
8	8	↓	Ch -
9	9	Pause	Pause
0	0	[+]	3D
Tv/ Radio	TV/ R	FAV	Pre Ch
↩PR	Back	UHF	Smart
EPG	Guide	PAL/ NTSC	Format
Menu	Menu	TV/ AV	AV
Info	Info	Red	Red

Original		Replacement		Original	Replacement
TXT	Green		Green		
	Yellow		Yellow		
	Blue		Blue		
AUDIO	Audio		Dual		
TXT	TXT	T	Text		
	[. . .]		Subt		
	Audio L/R		+ Shift + Dual		