Mandis shop

LSSQ0336

Original	Replacement
Start/Stop	Power
Play	Play / Slow
Pause/Item	Pause / Step / Freeze
Stop/Set	Stop / Hold
Rec	Rec / Rec Mode
<<	<< / Tune-
>>	>> / Tune+
I<< Index	I<< / Preset-
Index >>I	>>I / Preset+
A.DUB	Audio / Lang I/II
Photo Shot	Picture / Format
Date/Time	Sleep / Timer
Menu	Menu / Home
Zoom T	Up
<I Still Adv	Left
Still Adv I>	Right
Reset	Exit / Cancel / Clear

Original	Replacement
Zoom W	Down
Vol +	Vol +
Counter	Smart / List
Vol -	Vol -
OSD	Display / Media

https://mandis.tv/en/Panasonic/1676-105-replacement-remote-control-for-Panasonic-LSSQ0336.htm