Original		Replacement	
	Power		Power
	Mute	MUTE	Mute
REPEAT	Red/ Repeat	A	Red
PROG	Green/ Prog	B	Green
SLOW	Yellow/ Slow	C	Yellow
ANGLE	Blue/ Angle	D	Blue
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
	<<		<<
	>>		>>
GOTO FAV	Goto/ Fav	FAV PRE-CH	Pre Ch
	Eject	ZOOM	Eject
	I<<		I<<
	>>I		>>I
SETUP	Setup	SETTINGS OPT	Options
VCR	Vcr	PICTURE FORMAT	Format

Original		Replacement	
TV RADIO	TV/ Radio	SEARCH TV/R	TV/ R
RECALL	Recall	RETURN BACK	Back
MENU TXT	Menu	TOP MENU MENU	Menu
MENU TXT	Text	REPEAT TEXT	Text
EXIT	Exit	CLEAR EXIT	Exit
GUIDE	Guide	GUIDE	Guide
SOURCE	Source	TIMER AV	AV
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK CH LIST	Ok/ Ch List	OK	Ok
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
INFO	Info	DISPLAY INFO	Info
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject
CH+	Ch+	CH+	Ch +

Original		Replacement		Original		Replacement	
CH –	Ch-	CH –	Ch -				
1	1	1	1				
2	2	2	2				
3	3	3	3				
4	4	4	4				
5	5	5	5				
6	6	6	6				
7	7	7	7				
8	8	8	8				
9	9	9	9				
0	0	0	0				
AUDIO	Audi o	SOUND DUAL	Dual				
SUBTITLE	Subt i t l e	AD SUBT	Subt				