Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	Rec	REC MODE	Rec / Rec Mode
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	(O	LANG I/II AUDIO	Audio / Lang I/II
	[<>]	FORMAT PICTURE	Picture / Format
	Green/Timer	TIMER SLEEP	Sleep / Timer
	>I<	TOP MENU D.MENU	D.Menu / Top
	[1I2]	OPT-TOOLS SETUP	Setup / OPT /
	[≡]	GOTO TEXT	Text / Goto
	Source	RDS AV INPUT	AV / Input / RDS
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
	[i+]	ANGLE INFO	Info / Angle

Original		Replacement	
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
	Vol+	VOL +	Vol+
Active Control	[-O-]/Active Control	LIST SMART	Smart / List
P+	P+	CH PAGE +	CH+ / Page+
	Vol-	VOL −	Vol-
P-	P-	CH PAGE −	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8

Original	Replacement
9	9
Guide	Guide / EPG / -/--
0	0
P<P	Fav / Marker / PC
Red	Red / Netflix / Search
Green/Timer	Green / APP / Repeat
Yellow/[ ]	Yellow / YouTube / Repeat
Blue/[...]	Blue / Prime Video / Random
Power AMP	Shift + Power
Mute AMP	Shift + Mute / Dimmer
<< AMP	Shift + << /
>> AMP	Shift + >> /
[≡] AMP	Shift + Text /
Menu AMP	Shift + Menu /
Up AMP	Shift + Up
Left AMP	Shift + Left
OK AMP	Shift + OK

Original	Replacement
Right AMP	Shift + Right
Down AMP	Shift + Down
Vol+ AMP	Shift + Vol+
P+ AMP	Shift + CH+ /
Vol- AMP	Shift + Vol-
P- AMP	Shift + CH- /
1 AMP	Shift + 1
2 AMP	Shift + 2
3 AMP	Shift + 3
4 AMP	Shift + 4
5 AMP	Shift + 5
6 AMP	Shift + 6
7 AMP	Shift + 7
8 AMP	Shift + 8
9 AMP	Shift + 9
Guide AMP	Shift + Guide / EPG / -/--
0 AMP	Shift + 0

Original	Replacement	Original	Replacement
P<P AMP	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC		

Original	Replacement	Original	Replacement
Power	Power	P+	CH+ / Page+
Source	AV / Input / RDS	Vol-	Vol-
>>	>> / Tune+	P-	CH- / Page-
<<	<< / Tune-	1	1
Stop	Stop / Hold	2	2
Play	Play / Slow	3	3
Guide	Guide / EPG / -/--	4	4
[≡]	Text / Goto	5	5
Up	Up	6	6
Left	Left	7	7
OK	OK	8	8
Right	Right	9	9
Down	Down	[i+]	Info / Angle
>I<	D.Menu / Top	0	0
Menu	Menu / Home	P<P	Fav / Marker / PC
Vol+	Vol+	[1I2]	Setup / OPT /
Mute	Mute / Dimmer	[-O-]/Active Control	Smart / List

Original	Replacement	Original	Replacement
[<>]	Picture / Format		

Original	Replacement	Original	Replacement
Power	Power	OK	OK
Mute	Mute / Dimmer	Right	Right
Play	Play / Slow	Down	Down
Stop	Stop / Hold	Vol+	Vol+
Rec	Rec / Rec Mode	[-O-]/Active Control	Smart / List
<<	<< / Tune-	P+	CH+ / Page+
>>	>> / Tune+	Vol-	Vol-
(O	Audio / Lang I/II	P-	CH- / Page-
[<>]	Picture / Format	1	1
Green/Timer	Sleep / Timer	2	2
>I<	D.Menu / Top	3	3
[1I2]	Setup / OPT /	4	4
Source	AV / Input / RDS	5	5
Menu	Menu / Home	6	6
Up	Up	7	7
[i+]	Info / Angle	8	8
Left	Left	9	9

Original	Replacement
0	0
P<P	Fav / Marker / PC
Red	Red / Netflix / Search
Green/Timer	Green / APP / Repeat
Yellow/[ ]	Yellow / YouTube / Repeat
Blue/[...]	Blue / Prime Video / Random
Power VCR	Shift + Power
Play VCR	Shift + Play /
Stop VCR	Shift + Stop /
Rec VCR	Shift + Rec / Rec Mode
<< VCR	Shift + << /
>> VCR	Shift + >> /
>I< VCR	Shift + D.Menu / Top Menu
Source VCR	Shift + AV / Input / RDS
Menu VCR	Shift + Menu /
Up VCR	Shift + Up
[i+] VCR	Shift + Info / Angle

Original	Replacement
Left VCR	Shift + Left
OK VCR	Shift + OK
Right VCR	Shift + Right
Down VCR	Shift + Down
P+ VCR	Shift + CH+ /
P- VCR	Shift + CH- /
1 VCR	Shift + 1
2 VCR	Shift + 2
3 VCR	Shift + 3
4 VCR	Shift + 4
5 VCR	Shift + 5
6 VCR	Shift + 6
7 VCR	Shift + 7
8 VCR	Shift + 8
9 VCR	Shift + 9
0 VCR	Shift + 0
P<P VCR	Shift + Fav / Marker / PC

Original		Replacement	
	Power		Power
	>>		>> / Tune+
	<<		<< / Tune-
	Stop		Stop / Hold
	Play		Play / Slow
	Guide		Guide / EPG / -/--
	Up		Up
	Left		Left
	Right		Right
	Down		Down
	>I<		D.Menu / Top
	Vol+		Vol+
	Mute		Mute / Dimmer
	P+		CH+ / Page+
	Vol-		Vol-
	P-		CH- / Page-
	1		1

Original		Replacement	
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	[i+]		Info / Angle
	0		0
	P<P		Fav / Marker / PC