| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| FAV | FAV | FAV PRE-CH | Pre Ch |
| TXT | TXT | REPEAT TEXT | Text |
| | Red | A | Red |
| | Green | B | Green |
| | Yellow | C | Yellow |
| | Blue | D | Blue |

| Original | | Replacement | |
|---|---|---|---|
| GUIDE | Guide | -/-- GUIDE | Guide |
| ? | ? | SOUND DUAL | Dual |
| EXIT | Exit | CLEAR EXIT | Exit |
| MENU | Menu | TOP MENU MENU | Menu |
| TOOLS | Tools | SETTINGS OPT | Options |
| BACK | Back | RETURN BACK | Back |
| @ | @ | HOME SMART | Smart |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| OK | OK | OK | Ok |
| + VOL | Vol + | + VOL | Vol + |
| - VOL | Vol - | - VOL | Vol - |
| | Mute | MUTE | Mute |
| | Source | TIMER AV | AV |
| + P | P+ | + CH | Ch + |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| P | P- | CH – | Ch - | | |
| I< | I< | I<< | I<< | | |
| >I | >I | >>I | >>I | | |
| << | << | << | << | | |
| >> | >> | >> | >> | | |
| Rec | Rec | REC MODE | Rec | | |
| Play | Play | PLAY MODE | Play | | |
| Pause | Pause | II | Pause | | |
| Stop | Stop | ■ | Stop | | |
| 3D | 3D | ECO 3D | 3D | | |
| OO | OO | PICTURE FORMAT | Format | | |
| [...].. | [...].. | AD SUBT | Subt | | |
| NETFLIX | Netflix | SHIFT + APP MEDIA | Shift + Media | | |
| MY MEDIA | My Media | APP MEDIA | Media | | |
| | | | | | |
| | | | | | |
| | | | | | |