Mandis shop

Philips 996510023877

Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
SOUND	Sound	TITLE SOUND	Sound / Title
AUDIO SOURCE	Source Audio	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND	Eject / Surround
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
RADIO	Radio	PROGRAM TV/RADIO	TV/Radio /
HDMI SOURCE	Source/HDMI	RDS AV INPUT	AV / Input / RDS
AUDIO SETUP PROGRAM	Audio	HOME MENU	Menu / Home
	Up		Up
DOUBLE BASS	Double Bass	ANGLE INFO	Info / Angle
	Left		Left
OK	OK	OK	OK
	Right		Right
DELETE	Delete	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Original		Replacement	
	Down		Down
BACK	Back	RETURN BACK	Back / Return
VOL+	Vol +	VOL +	Vol +
VOL−	Vol -	VOL −	Vol -
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0