Original		Sustituto	
	Power		Power
DVB Analogue MODE	Mode DVB	OPT-TOOLS SETUP	Setup / OPT /
DIRECT TV REC	Direct TV Rec	REC MODE	Rec / Rec Mode
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	Up		Up
TV/AV	TV / AV	RDS AV INPUT	AV / Input / RDS
	Left		Left
OK	OK	OK	OK
	Right		Right
MENU	Menu	HOME MENU	Menu / Home
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
TEXT	Text	GOTO TEXT	Text / Goto

Original		Sustituto	
STTL	STTL / FP	EQ SUBTITLE	Subtitle / EQ
INDEX	Index	LIST SMART	Smart / List
HOLD	Hold	SHIFT + HOLD	Shift + Stop /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
C	C	PC FAV MARKER	Fav / Marker / PC
0 VCR	0 / VCR	HDMI - SAT 0	0
i	i	ANGLE INFO	Info / Angle
^	CH +	CH PAGE +	CH+ / Page+
+	Vol +	VOL +	Vol +

Original		Sustituto		Original	Sustituto
V	CH -	CH PAGE −	CH- / Page-		
Vol −	Vol -	VOL −	Vol -		
ASPECT	Aspect	FORMAT PICTURE	Picture / Format		
N	N	MEDIA DISPLAY	Display / Media		
Mute	Mute	DIMMER MUTE	Mute / Dimmer		
DVD Power	DVD Power	SHIFT +	Shift + Power		
REC	DVD Rec	SHIFT + REC MODE	Shift + Rec / Rec Mode		
PROGR V	DVD Programe -	SHIFT + CH PAGE −	Shift + CH- /		
GRAMME ^	DVD Programe	SHIFT + CH PAGE +	Shift + CH+ /		
⏮ ◀◀	DVD << / I<<	PRESET- ⏮	I<< / Preset-		
⏮ ◀◀	DVD << / I<<	TUNE- ◀◀	<< / Tune-		
⏭ ▶▶	DVD >> / >>I	TUNE+ ▶▶	>> / Tune+		
⏭ ▶▶	DVD >> / >>I	PRESET+ ⏭	>>I / Preset+		
■	DVD Stop	HOLD ■	Stop / Hold		
II/▶	DVD Pause / Step	STEP-FREEZE II	Pause / Step / Freeze		
▶	DVD Play	SLOW ▶	Play / Slow		

Original		Sustituto	
	VCR Power		Power
REC	VCR Rec	REC MODE	Rec / Rec Mode
PROGR	VCR	CH PAGE	CH- / Page-
RAMME	VCR	CH PAGE	CH+ / Page+
	VCR << / I<<	PRESET-	I<< / Preset-
	VCR << / I<<	TUNE-	<< / Tune-
	VCR >> / >>I	TUNE+	>> / Tune+
	VCR >> / >>I	PRESET+	>>I / Preset+
	VCR Stop	HOLD	Stop / Hold
	VCR Pause / Step	STEP-FREEZE	Pause / Step / Freeze
	VCR Play	SLOW	Play / Slow

Original	Sustituto