Original		Sustituto	
	Power		Power
	TV / Video	SEARCH TV/R	TV/R
	DVD	HOME SMART	Smart
	VCR	APP MEDIA	Media
	Open / Close	ZOOM	Eject
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
DISPLAY	Display	DISPLAY INFO	Info
	Up		Up

Original		Sustituto	
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play
PAUSE/STEP	Pause / Step		Pause
REW	<< REW		<<
FWD	>> FWD		>>
RECORD	Record	REC MODE	Rec
CLEAR	Clear	CLEAR EXIT	Exit

Original		Sustituto	
	Power		Power
	Open / Close		Eject
	DVD	HOME SMART	Smart
	VCR	APP MEDIA	Media
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
RETURN	Return	RETURN BACK	Back
DISPLAY	Display	DISPLAY INFO	Info
LIST/DISC MENU	List / Disc Menu	E-MANUAL D.MENU	D. Menu

Original		Sustituto	
SYSTEM MENU	System Menu	TOP MENU MENU	Menu
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
	I<		I<<
	>I		>>I
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play
PAUSE/STEP	Pause / Step		Pause
REW	<< REW		<<
FWD	>> FWD		>>
THUMBNAIL	Thumbnail	ECO 3D	3D
CHAPTER	Chapter	PICTURE FORMAT	Format
TIMER	Timer	TIMER AV	AV
RECORD	Record	REC MODE	Rec

Original	Sustituto	Original	Sustituto
REC MODE — Rec. Mode	D — Blue		
REPEAT — Repeat	REPEAT TEXT — Text		
TITLE — Title	SETTINGS OPT — Options		
AUDIO — Audio	SOUND DUAL — Dual		
ZOOM — Zoom	SHIFT + ZOOM — Shift + Eject		
SEARCH — Search	SEARCH TV/R — TV/R		
MARKER — Marker	FAV PRE-CH — Pre Ch		
D.DUBBING — D. Dubbing	-/-- GUIDE — Guide		
CLEAR — Clear	CLEAR EXIT — Exit		
SHOWVIEW VIDEOPLUS+ — Showview / VideoPlus+	AD SUBT — Subt		