Original	Sustituto	Original	Sustituto
On / Standby	Power	Volume+	Vol +
CBL/SAT	Shift + 0	CH/Page-	CH- / Page-
DVD	Shift + 2	Sleep	Sleep / Timer
TV Audio	Audio / Lang I/II	Mute	Mute / Dimmer
Blu-ray	Shift + 1	Volume-	Vol -
AUX1	Shift + 7	Info	Info / Angle
M-XP	Fav / Marker / PC	Up	Up
Tuner	Shift + 6	Option	Shift + Setup / OPT / Tools
Game	Shift + Fav / Marker / PC	Option	D.Menu / Top
AUX2	Shift + 4	Left	Left
Phono	Shift + 9	Enter	OK
iPod/USB	Shift + 8	Right	Right
Media Player	Shift + 5	Back	Back / Return
CD	Shift + 3	Down	Down
Network	Guide / EPG / -/--	Setup	Setup / OPT /
Internet Radio	Shift + Guide / EPG / -/--	Pause	Pause / Step / Freeze
CH/Page+	CH+ / Page+	Stop	Stop / Hold

Original		Sustituto	
	Play	SLOW	Play / Slow
TUNE-	I<< / Tune-	SHIFT + TUNE-	Shift + << /
TUNE-	I<< / Tune-	PRESET-	I<< / Preset-
NE +	Tune+ / >>I	SHIFT + TUNE+	Shift + >> /
NE +	Tune+ / >>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
1	Favorite Station	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
FAVORITE 2	Favorite Station	SHIFT + APP REPEAT	Shift + Green / APP /
STATION 3	Favorite Station	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
4	Favorite Station	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
MOVIE	Red / Movie	NETFLIX SEARCH	Red / Netflix / Search
MUSIC SOUND	Green / Music	APP REPEAT	Green / APP / Repeat
GAME	Blue / Game	Prime Video RANDOM	Blue / Prime Video / Random
PURE	Yellow / Pure	YouTube REPEAT A-B	Yellow / YouTube / Repeat
1	1	TV 1	1
SOUND 2	2	DVD 2	2

Original		Sustituto	
MODE 3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0

Original		Sustituto	
ON/STANDBY	On / Standby		Power
CBL/ SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
DVD	DVD	SHIFT + DVD 2	Shift + 2
TV AUDIO	Tv Audio	LANG I/II AUDIO	Audio / Lang I/II
Blu-ray	Blu-ray	SHIFT + TV 1	Shift + 1
AUX1	AUX1	SHIFT + AUX - HDD 7	Shift + 7
M-XP	M-XP	PC FAV MARKER	Fav / Marker / PC
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
GAME	Game	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
AUX2	AUX2	SHIFT + VIDEO 4	Shift + 4
PHONO	Phono	SHIFT + BLUETOOTH 9	Shift + 9
iPod/ USB	iPod/USB	SHIFT + USB 8	Shift + 8
MEDIA PLAYER	Media Player	SHIFT + TAPE 5	Shift + 5
CD	CD	SHIFT + CD - STB 3	Shift + 3
NETWORK	Network	-/-- GUIDE EPG	Guide / EPG / -/--
INTERNET RADIO	Internet Radio	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
CH/PAGE	CH/Page+	CH	CH+ / Page+

Original		Sustituto	
VOLUME	Volume+	VOL	Vol +
CH/PAGE	CH/Page-	CH PAGE	CH- / Page-
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOLUME	Volume-	VOL	Vol -
	Up		Up
	Left		Left
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
— TUNE	Pause	STEP - FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
— TUNE	I <</Tune-	SHIFT + TUNE-	Shift + << /
— TUNE	I <</Tune-	PRESET-	I << / Preset-
NE +	>>I / Tune+	SHIFT + TUNE+	Shift + >> /
NE +	>>I / Tune+	PRESET+	>>I / Preset+

Original		Sustituto		Original	Sustituto
	<<		<< / Tune-		
	>>		>> / Tune+		
	Favorite Station		Red / Netflix / Search		
	Favorite Station		Green / APP / Repeat		
	Favorite Station		Yellow / YouTube / Repeat		
	Favorite Station		Blue / Prime Video / Random		
	1		1		
	2		2		
	3		3		
	4		4		
	5		5		
	6		6		
	7		7		
	8		8		
	9		9		
	0		0		
	Enter		OK		

Original		Sustituto		Original		Sustituto	
ON/STANDBY	ON / Standby		Power	VOLUME	Volume+	VOL +	Vol +
CBL/ SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0		CH/Page-	CH PAGE −	CH- / Page-
DVD	DVD	SHIFT + DVD 2	Shift + 2	SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TV AUDIO	Tv Audio	LANG I/II AUDIO	Audio / Lang I/II	MUTE	Mute	DIMMER MUTE	Mute / Dimmer
Blu-ray	Blu-ray	SHIFT + TV 1	Shift + 1		Volume-	VOL −	Vol -
AUX1	AUX1	SHIFT + AUX - HDD 7	Shift + 7		Up		Up
M-XP	M-XP	PC FAV MARKER	Fav / Marker / PC		Left		Left
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6		Right		Right
GAME	Game	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC	BACK	Back	RETURN BACK	Back / Return
AUX2	AUX2	SHIFT + VIDEO 4	Shift + 4		Down		Down
PHONO	Phono	SHIFT + BLUETOOTH 9	Shift + 9		Pause	STEP - FREEZE	Pause / Step / Freeze
iPod/ USB	iPod/USb	SHIFT + USB 8	Shift + 8		Stop	HOLD	Stop / Hold
MEDIA PLAYER	Media Player	SHIFT + TAPE 5	Shift + 5		Play	SLOW	Play / Slow
CD	CD	SHIFT + CD - STB 3	Shift + 3	TUNE −	I <</Tune-	SHIFT + TUNE-	Shift + << /
NETWORK	Network	GUIDE EPG	Guide / EPG / -/--	TUNE −	I <</Tune-	PRESET-	I << / Preset-
INTERNET RADIO	Internet Radio	SHIFT + GUIDE EPG	Shift + Guide / EPG / -/--	TUNE +	>>I / Tune+	SHIFT + TUNE+	Shift + >> /
CH/PAGE	CH/Page+	CH PAGE +	CH+ / Page+	TUNE +	>>I / Tune+	PRESET+	>>I / Preset+

Original		Sustituto		Original	Sustituto
	<<		<< / Tune-		
	>>		>> / Tune+		
	Favorite Station		Red / Netflix / Search		
	Favorite Station		Green / APP / Repeat		
	Favorite Station		Yellow / YouTube / Repeat		
	Favorite Station		Blue / Prime Video / Random		
	1		1		
	2		2		
	3		3		
	4		4		
	5		5		
	6		6		
	7		7		
	8		8		
	9		9		
	0		0		
	Enter		OK		