Original		Sustituto	
	Power		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+10	+10	GUIDE	Guide
CANCEL	Cancel	CLEAR EXIT	Exit
DVD	DVD	D	Blue
iPod/USB	iPod/USB	B	Green
FM/EXT-IN	FM/EXT-In	C	Yellow
ONE TOUCH PLAY	One touch play	ZOOM	Eject

Original		Sustituto	
VOL +	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
SKIP	I<< Skip/Down		I<<
	Up/Skip >>I		>>I
SLOW/S	<< Slow/Search		<<
SEARCH	Slow/Search >>		>>
STOP	Stop		Stop
PAUSE	Pause		Pause
PLAY	Play	PLAY MODE	Play
START	Start	HOME SMART	Smart
TOP MENU DIRECT NAVIGATOR	Top Menu/Direct Navigator	DISC NAV LIST	List
MENU PLAY LIST	Menu/Play List	TOP MENU MENU	Menu
RETURN	Return	RETURN BACK	Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Sustituto	
OK	OK	OK	Ok
FUNCTIONS	Functions	E-MANUAL D.MENU	D. Menu
PLII	[O O] PLII	SOUND DUAL	Dual
PLAY MODE -REPEAT	Play Mode/Repeat	REPEAT TEXT	Text
FL DISPLAY -SLEEP	FL Display-Sleep	PROG SLEEP	Sleep
SOUND -W.S.	Sound-W.S.	AD SUBT	Subt
SUBWOOFER LEVEL -CH SELECT	Level/Subwoofer/ CH Select	SEARCH TV/R	TV/R
SETUP	Setup	SETTINGS OPT	Options
MUTING	Muting	MUTE	Mute
TV	Power Tv	SHIFT +	Shift + Power
TV/AV	Tv/AV Tv	TIMER AV	AV
VOL +	Vol + Tv	SHIFT + VOL +	Shift + Vol +
VOL -	Vol - Tv	SHIFT + VOL -	Shift + Vol -

Original	Sustituto