Original		Sustituto		Original		Sustituto	
POWER	Power		Power	INPUT	Input	RDS AV INPUT	AV / Input / RDS
EJECT	Eject	SURROUND	Eject / Surround	SPEED	Speed	NETFLIX SEARCH	Red / Netflix / Search
1	1	TV 1	1	AFT	AFT	APP REPEAT	Green / APP / Repeat
2	2	DVD 2	2	FINE	Fine Up	VOL +	Vol +
3	3	CD - STB 3	3	PROG	Prog Up	CH PAGE +	CH+ / Page+
SYSTEM	System	TOP MENU D.MENU	D.Menu / Top	INDEX	Index	YouTube REPEAT A-B	Yellow / YouTube / Repeat
4	4	VIDEO 4	4	A.TRK	A.TRK	Prime Video RANDOM	Blue / Prime Video / Random
5	5	TAPE 5	5	FINE	Fine Down	VOL −	Vol -
6	6	TUNER 6	6	PROG	Prog Down	CH PAGE −	CH- / Page-
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II		<< Shuttle	PRESET-	I<< / Preset-
7	7	AUX - HDD 7	7		Shutle >>	PRESET+	>>I / Preset+
8	8	USB 8	8	PLAY	Play	SLOW	Play / Slow
9	9	BLUETOOTH 9	9	REW	<<	TUNE-	<< / Tune-
DISPLAY	Display	MEDIA DISPLAY	Display / Media	F.F	>>	TUNE+	>> / Tune+
CLK/COUNT	CLK/Count	-/-- GUIDE EPG	Guide / EPG / -/--	STOP	Stop	HOLD	Stop / Hold
0	0	HDMI - SAT 0	0	REC	Rec	REC MODE	Rec / Rec Mode
CLR/RST	CLR/RST	CLEAR EXIT CANCEL	Exit / Cancel / Clear	P/S	P/S	STEP - FREEZE	Pause / Step / Freeze

Original		Sustituto		Original	Sustituto
MENU	Menu	HOME MENU	Menu / Home		
	Up		Up		
Q-PRO	Q-Pro	LIST SMART	Smart / List		
SOFTEN	Left / Soften / Slow-		Left		
OK	OK	OK	OK		
SHARPEN	Right / Sharpen Slow+		Right		
PICTURE	Picture	FORMAT PICTURE	Picture / Format		
	Down		Down		
	TV/VCR	PC FAV MARKER	Fav / Marker / PC		