Mandis shop

# Sharp RRMCGA178AWSA

| Original | | Sustituto | |
|---|---|---|---|
| | Standby | | Power |
| | Virtual Speaker | SOUND DUAL | Dual |
| STANDARD | Standard | PICTURE FORMAT | Format |
| CINEMA/GAME | Cinema/Game | APP MEDIA | Media |
| SPORT | Sport | HOME SMART | Smart |
| NEWS | News | DISPLAY INFO | Info |
| VOLUME + | Vol+ | VOL + | Vol + |
| VOLUME − | Vol- | VOL − | Vol - |
| MUTE | Mute | MUTE | Mute |
| SUBWOOFER LEVEL ^ | Level Subwoofer | | Up |
| SUBWOOFER LEVEL v | Level Subwoofer Down | | Down |
| BASS/TREBLE | Bass/Treble | REPEAT TEXT | Text |
| DIMMER | Dimmer | DISC NAV LIST | List |
| LINE | Line | PROG SLEEP | Sleep |
| DIGITAL 1 | Digital 1 | 1 | 1 |
| DIGITAL 2 | Digital 2 | 2 | 2 |
| ON/STAND-BY | Standby Tv | SHIFT + | Shift + Power |

| Original | | Sustituto | |
|---|---|---|---|
| INPUT | Input | TIMER AV | AV |
| CHANNEL ^ | CH+ Tv | CH + | Ch + |
| CHANNEL v | CH- Tv | CH − | Ch - |
| VOLUME + | Vol+ Tv | SHIFT + VOL + | Shift + Vol + |
| VOLUME − | Vol- Tv | SHIFT + VOL − | Shift + Vol - |

https://mandos-a-distancia.es/es/Sharp/1059701-2392-mando-de-sustitucion-para-Sharp-RRMCGA178AWSA.html