Original		Substitut	
	Power		Power
	Mute	MUTE	Mute
NET+	Net +	HOME SMART	Smart
DTV	DTV	E-MANUAL D.MENU	D. Menu
USB	USB	SETTINGS OPT	Options
YouTube	YouTube	APP MEDIA	Media
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	Recall	FAV PRE-CH	Pre Ch

Original		Substitut	
TV GUIDE	Tv Guide	GUIDE	Guide
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
SOUND	Sound	SHIFT + SOUND DUAL	Shift + Dual
PICTURE	Picture	PICTURE FORMAT	Format
SOURCE	Source	TIMER AV	AV
CH +	CH+	CH +	Ch +
CH −	CH-	CH −	Ch -
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
BACK	Back	RETURN BACK	Back
FAV	FAV	SHIFT + FAV PRE-CH	Shift + Pre Ch
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok

Original		Substitut	
INFO	Info	DISPLAY INFO	Info
SLEEP	Sleep	PROG SLEEP	Sleep
AUDIO	Audio	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
TEXT	Text	REPEAT TEXT	Text
TEXT HOLD	Text/Hold	SEARCH TV/R	TV/R
TEXT/DVD ZOOM	Text/DVD/Zoom	ZOOM ⏏	Eject
DISPLAY ⏻	Power Display	SHIFT + ⏻	Shift + Power
●	Rec	REC MODE ●	Rec
⏮	I<<	⏮	I<<
⏭	>>I	⏭	>>I
■	Stop	■	Stop
REC LIST	Rec List	DISC NAV LIST	List
◀◀	<< PVR Media	◀◀	<<
▶▶	>> PVR Media	▶▶	>>
▶II	Play	PLAY MODE ▶	Play
▶II	Pause	II	Pause

Original		Substitut	
GOTO	Red/Goto	A	Red
A-B	Green/A-B	B	Green
ANGLE 3D	Yellow/Angle/3D	C	Yellow
REPEAT	Blue/Repeat	D	Blue