Original		Substitut	
	Power		Power
SOURCE	Source	TIMER AV	AV
OFF	Off	SHIFT +	Shift + Power
.QZ 1	1	1	1
ABC 2	2	2	2
DEF 3	3	3	3
GHI 4	4	4	4
JKL 5	5	5	5
MNO 6	6	6	6
PRS 7	7	7	7
TUV 8	8	8	8
WXY 9	9	9	9
SYMBOL 0	0	0	0
DEL-/--	- - / Del / - / - -	-/-- GUIDE	Guide
D.MENU	D. Menu	E-MANUAL D.MENU	D. Menu
+ VOL	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -

Original		Substitut	
MUTE	Mute	MUTE	Mute
CONTENT (HOME)	Content / Home	HOME SMART	Smart
CH	CH+	+ CH	Ch +
CH	CH-	CH −	Ch -
MagicInfo Lite	MagicInfo Lite	AD SUBT	Subt
MENU	Menu	TOP MENU MENU	Menu
BLANK	Blank	SEARCH TV/R	TV/R
TOOLS	Tools	SETTINGS OPT	Options
INFO i	Info	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
	Enter	OK	Ok
PC A	Red/PC	A	Red

Original		Substitut	
DVI B	Green/DVI	B	Green
HDMI C	Yellow/HDMI	C	Yellow
DP D	Blue/DP	D	Blue
MagicInfo	MagicInfo	APP MEDIA	Media
3D	3D	ECO 3D	3D
LOCK	Lock	ZOOM	Eject
■	Stop	■	Stop
◀◀	<<	<<	<<
◀◀	I <<	I <<	I <<
▶	Play	PLAY MODE ▶	Play
II	Pause	II	Pause
▶▶	>>I	>>I	>>I
▶▶	>>	>>	>>

Original	Substitut