Original	Substitut	Original	Substitut
Power	Power	0	0
Repeat	Green / APP / Repeat	10+	Guide / EPG / -/--
A-B	Yellow / YouTube / Repeat	Time	Sleep / Timer
Open / Close	Eject / Surround	Setup	Setup / OPT /
N / P	D. Menu / Top	Up	Up
1	1	Title	Sound / Title
2	2	Left	Left
3	3	Enter	OK
Subtitle	Subtitle / EQ	Right	Right
4	4	PBC	Picture / Format
5	5	Down	Down
6	6	Menu	Menu / Home
Angle	Info / Angle	Vol -	Vol -
7	7	Zoom	Zoom / Size
8	8	Vol +	Vol +
9	9	Return	Back / Return
Language	Audio / Lang I/II	L / R	Text / Goto

Original	Substitut	Original	Substitut
STEP Step	SHIFT + STEP-FREEZE Shift + Pause / Step /		
SLOW Slow	SHIFT + SLOW Shift + Play /		
PROGRAM Program	PROGRAM TV/RADIO TV/Radio /		
CLEAR Clear	CLEAR EXIT CANCEL Exit / Cancel / Clear		
MUTE Mute	DIMMER MUTE Mute / Dimmer		
DISPLAY Display	MEDIA DISPLAY Display / Media		
PREV Prev I<<	PRESET- I<< / Preset-		
NEXT Next >>I	PRESET+ >>I / Preset+		
REV Rev <<	TUNE- << / Tune-		
FWD Fwd >>	TUNE+ >> / Tune+		
V-MODE V-Mode	LIST SMART Smart / List		
STOP Stop	HOLD Stop / Hold		
PLAY/PAUSE Play / Pause	SLOW Play / Slow		
PLAY/PAUSE Play / Pause	STEP-FREEZE Pause / Step / Freeze		