Mandis shop

Sony RM-947

Original	Substitut	Original	Substitut
Power	Power	Blue	Blue
Source	AV	♪	Dual
1	1	☼	Format
2	2	[ ]	TV/R
3	3	[≡]	Text
4	4	Menu	Menu
5	5	[+]	3D
6	6	Up	Up
7	7	Down	Down
8	8	Right	Right
9	9	Left	Left
0	0	OK	Ok
[i+]/[?]	Info	Vol +	Vol +
Recall	Pre Ch	Vol -	Vol -
Red	Red	Mute	Mute
Green	Green	Prog+	Ch +
Yellow	Yellow	Prog-	Ch -

https://mandis-distance.com/sony/1598-654-comment-substituer-sony-RM-947-17642.htm