| Original | | Substitut | |
|---|---|---|---|
| | Power | | Power |
| DIRECT TV REC | Direct Tv Rec | SHIFT + REC MODE | Shift + Rec / Rec Mode |
| AV LINK/ TV ASPECT | Tv Aspect/AV Link | FORMAT PICTURE | Picture / Format |
| TV/TEXT | Tv/Text | GOTO TEXT | Text / Goto |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| CKING/V-LOCK + | Tracking/V-Lock+ | + CH PAGE | CH+ / Page+ |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| - | Tracking/V-Lock- | CH PAGE - | CH- / Page- |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| VOLUME + | Vol+ | + VOL | Vol+ |
| INPUT SELECT AV | AV/Input Select | RDS AV INPUT | AV / Input / RDS |

| Original | | Substitut | |
|---|---|---|---|
| 0 | 0 | HDMI-SAT 0 | 0 |
| -/-- | -/-- | -/-- GUIDE EPG | Guide / EPG / -/-- |
| – | Vol- | VOL – | Vol- |
| LIBRARY/SEARCH | Library/Search | NETFLIX SEARCH | Red / Netflix / Search |
| INDEX | I<< Index | PRESET- | I<< / Preset- |
| INDEX | Index >>I | PRESET+ | >>I / Preset+ |
| ShowView | ShowView | ANGLE INFO | Info / Angle |
| STILL ALBUM | Still Album | LIST SMART | Smart / List |
| REPLAY | Replay | RETURN BACK | Back / Return |
| II/▶ | Pause/Step | STEP-FREEZE II | Pause / Step / Freeze |
| REC | Rec | REC MODE | Rec / Rec Mode |
| MENU | Menu | HOME MENU | Menu / Home |
| ▲ | Up | ▲ | Up |
| ▶ | Play | SLOW ▶ | Play / Slow |
| EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| ◀ | Left | ◀ | Left |
| ◀◀ | << | TUNE- ◀◀ | << / Tune- |

| Original | | Substitut | |
|---|---|---|---|
| OK | OK | OK | OK |
| Right | Right | Right | Right |
| >> | >> | TUNE+ | >> / Tune+ |
| Down | Down | Down | Down |
| Stop | Stop | HOLD | Stop / Hold |
| Prog./Check Up | Prog./Check Up | SHIFT + | Shift + Up |
| Date+ | Date+ | SHIFT + | Shift + Right |
| On+ | On+ | SHIFT + VOL | Shift + Vol+ |
| Off+ | Off+ | SHIFT + CH PAGE | Shift + CH+ / |
| Prog./Check Down | Prog./Check Down | SHIFT + | Shift + Down |
| Date- | Date- | SHIFT + | Shift + Left |
| On- | On- | SHIFT + VOL | Shift + Vol- |
| Off- | Off- | SHIFT + CH PAGE | Shift + CH- / |
| Prog.Check | Prog.Check | PROGRAM TV/RADIO | TV/Radio / |
| Cancel | Cancel | SHIFT + CLEAR EXIT CANCEL | Shift + Exit / Cancel / Clear |
| SP/LP/EP | SP/LP/EP | OPT-TOOLS SETUP | Setup / OPT / |
| Timer | Timer | TIMER SLEEP | Sleep / Timer |

| Original | | Substitut | |
|---|---|---|---|
| I-Timer | I-Timer | SHIFT + TIMER SLEEP | Shift + Sleep / Timer |
| Audio | Audio | LANG I/II AUDIO | Audio / Lang I/II |
| OSD/Display | OSD/Display | MEDIA DISPLAY | Display / Media |
| Reset | Reset | APP REPEAT | Green / APP / Repeat |

| Original | | Substitut | |
|---|---|---|---|
| | Power | | Power |
| AV LINK/ TV ASPECT | Tv Aspect/AV Link | FORMAT PICTURE | Picture / Format |
| TV/TEXT | Tv/Text | GOTO TEXT | Text / Goto |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| CKING/V-LOCK + | Tracking/V.Lock+ | + CH PAGE | CH+ / Page+ |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| - | Tracking/V.Lock- | CH PAGE – | CH- / Page- |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| VOLUME + | Vol+ | + VOL | Vol+ |
| INPUT SELECT AV | AV/Input Select | RDS AV INPUT | AV / Input / RDS |
| 0 | 0 | HDMI - SAT 0 | 0 |

| Original | | Substitut | |
|---|---|---|---|
| -/-- | -/-- | -/-- GUIDE EPG | Guide / EPG / -/-- |
| – | Vol- | VOL – | Vol- |
| ^ | Prog./Check Up | ▲ | Up |
| ^ | Red | NETFLIX SEARCH | Red / Netflix / Search |
| + DATE | Green | APP REPEAT | Green / APP / Repeat |
| + DATE | Date+ | ▶ | Right |
| + ON | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| + ON | On+ | SHIFT + + VOL | Shift + Vol+ |
| + OFF | Blue | Prime Video RANDOM | Blue / Prime Video / Random |
| + OFF | Off+ | SHIFT + + CH PAGE | Shift + CH+ / |
| PROG./CHECK | Prog./Check Down | ▼ | Down |
| DATE – | Date- | ◀ | Left |
| ON – | On- | SHIFT + VOL – | Shift + Vol- |
| OFF – TIMER | Off- | SHIFT + CH PAGE – | Shift + CH- / |