Mandis shop

RM-SCP100

Original		Substitut	
I / ⏻	Power	⏻	Power
DSG	DSG	SOUND DUAL	Dual
DISPLAY	Display	DISPLAY INFO	Info
CD	Play CD	PLAY MODE ▶	Play
⏸	Pause	⏸	Pause
■	Stop	■	Stop
TUNER/BAND	Play	APP MEDIA	Media
⏮	I<< / Tuner -	⏮	I<<
⏭	>>I / Tuner +	⏭	>>I
TAPE	Play / Rev Tape	SHIFT + PLAY MODE ▶	Shift + Play
◀◀	<<	◀◀	<<
▶▶	>>	▶▶	>>
DIR MODE	Dir Mode	1	1
PLAY MODE	Play Mode	2	2
REC	Rec	REC MODE	Rec
CD REPEAT	CD Repeat	HOME SMART	Smart
STEREO/ MONO	Stereo / Mono	SETTINGS OPT	Options

Original		Substitut	
TUNING MODE	Tuning Mode	3	3
MEMORY	Up/Memory	▲	Up
TIMER SET	Left/Timer Set	◀	Left
ENTER ON/ OFF	Enter/On/Off	OK	Ok
TIMER SELECT	Right/Timer	▶	Right
SLEEP	Down/Sleep	▼	Down
SLEEP	Down/Sleep	SHIFT + ⏻	Shift + Power
VOL	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -

https://mandos-a-distancia.es/ca/Sony/1059676-81384-comandament-de-substitucio-per-Sony-RMSCP100.html