Original		Substitut	
1	1	1	1
AUX	AUX	TIMER AV	AV
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7/P	7/P	7	7
8	8	8	8
9	9	9	9
0	0	0	0
10 RETURN	10/Return	SHIFT + -/-- GUIDE	Shift + Guide
+10	+10/+100	FAV PRE-CH	Pre Ch
TA/NEWS/INFO	Play/TA/News/Inf	PLAY MODE ▶	Play
PTY SEARCH	Pause/PTY Search	⏸	Pause
DISPLAY MODE	Stop/Display	■	Stop
PTY+ FF	>>I/PTY+	⏭	>>I

Original		Substitut	
PTY- REW	I<</PTY-	⏮	I<<
FM/AM	FM/AM	HOME SMART	Smart
FM MODE	FM Mode	APP MEDIA	Media
PTY SEARCH ⏸	Pause FM/AM	OK	Ok
TA/NEWS/INFO ▶	Play FM/AM	▲	Up
DISPLAY MODE ■	Stop FM/AM	▼	Down
PTY+ FF	>>I FM/AM	▶	Right
PTY- REW	I<<FM/AM	◀	Left
TEST	Test	SETTINGS OPT	Options
EFFECT	Effect	SOUND DUAL	Dual
*SURR L	Level - SURR L	VOL −	Vol -
*SURR L	Level + SURR L	+ VOL	Vol +
1	1 FM/AM	SHIFT + 1	Shift + 1
2	2 FM/AM	SHIFT + 2	Shift + 2
3	3 FM/AM	SHIFT + 3	Shift + 3
4	4 FM/AM	SHIFT + 4	Shift + 4
5	5 FM/AM	SHIFT + 5	Shift + 5

Original	Substitut	Original	Substitut
6 FM/AM	SHIFT + 6 — Shift + 6		
7 FM/AM	SHIFT + 7 — Shift + 7		
8 FM/AM	SHIFT + 8 — Shift + 8		
9 FM/AM	SHIFT + 9 — Shift + 9		
10 FM/AM	GUIDE — Guide		
+10 FM/AM	SHIFT + FAV PRE-CH — Shift + Pre Ch		
*SURR R Level + SURR R	CH + — Ch +		
*SURR R Level - SURR R	CH − — Ch -		
*CENTER Level + Center	>>		
*CENTER Level - Center	<<		
*SUBWFR Level + SUBWFR	SEARCH TV/R — TV/R		
*SUBWFR Level - SUBWFR	ECO 3D — 3D		
*FRONT L Level + Front L	B — Green		
*FRONT L Level - Front L	A — Red		
*FRONT R Level + Front R	D — Blue		
*FRONT R Level - Front R	C — Yellow		

Original		Substitut		Original		Substitut	
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				
ENTER	Enter	OK	Ok				
MENU	Menu	TOP MENU MENU	Menu				
PTY SEARCH	Pause/ PTY Search		Pause				
TA/NEWS/INFO	Play/ TA/ News/ Inf	PLAY MODE	Play				
DISPLAY MODE	Stop/ Display		Stop				
REW PTY-	I <</ PTY-		I <<				
PTY+ FF	>>I / PTY+		>>I				
TA/NEWS/INFO	Play VCR	2	2				
PTY SEARCH	Pause VCR	5	5				
DISPLAY MODE	Stop VCR	8	8				
PTY+ FF	>>I VCR	6	6				
REW PTY-	I << VCR	4	4				
REC PAUSE	Rec Pause VCR	REC MODE	Rec				

Original		Substitut	
AUDIO	Audio Standby		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7/P	7/P	7	7
TV CH+	Tv CH+	CH +	Ch +
TV CH-	Tv CH-	CH -	Ch -
VCR CH+	VCR CH+	SHIFT + CH +	Shift + Ch +
VCR CH-	VCR CH-	SHIFT + CH -	Shift + Ch -
TV	TV Standby	A	Red
VCR	VCR Standby	B	Green
DVD	DVD Standby	C	Yellow
TA/NEWS/INFO	Play/TA/News/Inf	PLAY MODE	Play
PTY SEARCH	Pause/PTY Search		Pause

Original		Substitut	
DISPLAY MODE	Stop/Display		Stop
SLEEP	Sleep	PROG SLEEP	Sleep
PTY+ FF	>>I / PTY+		>>I
PTY- REW	I<< / PTY-		I<<
TV/VIDEO	Tv/Video	SEARCH TV/R	TV/R
ANALOG/ DIGITAL	Analog/Digital	APP MEDIA	Media
DIMMER	Dimmer	ECO 3D	3D
SURROUND	Surround	SOUND DUAL	Dual
DSP	DSP	TIMER AV	AV
SURROUND/ DSP OFF	Surround DSP	AD SUBT	Subt
VOLUME +	Vol +	VOL +	Vol +
VOLUME -	Vol -	VOL -	Vol -
TV VOLUME	Tv Vol +		Right
TV VOLUME	Tv Vol -		Left
MUTING	Muting	MUTE	Mute
VCR	VCR	RETURN BACK	Back
FM/AM	FM/AM	SETTINGS OPT	Options

Original	Substitut	Original	Substitut
FM MODE FM Mode	REPEAT TEXT Text		

Original		Substitut	
REC PAUSE	Rec Pause	REC MODE	Rec
PTY SEARCH	Pause		Pause
DISPLAY MODE	St op		St op
TA/NEWS/INFO	Pl ay	PLAY MODE	Pl ay
PTY FF	>>I		>>I
PTY REW	I <<		I <<
TV SOUND	TV Sound	HOME SMART	Smart
1	1 TV Sound	1	1
2	2 TV Sound	2	2
3	3 TV Sound	3	3
4	4 TV Sound	4	4
5	5 TV Sound	5	5
6	6 TV Sound	6	6
7/P	7 TV Sound	7	7
8	8 TV Sound	8	8
9	9 TV Sound	9	9
0	0 TV Sound	0	0

Original		Substitut	
10 RETURN	10 TV Sound	-/-- GUIDE	Gui de
+10	+10 TV Sound	FAV PRE-CH	Pre Ch