Mandis shop

LG COV33552434

Original		Substitut	
POWER	Power	POWER	Power
F	F	TOP MENU MENU	Menu
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
MUTE	Mute	MUTE	Mute
MEMORY	Memory	HOME SMART	Smart
PRESET / FOLDER Up	Preset / Folder Up	CH +	Ch +
PRESET / FOLDER	Preset / Folder	CH -	Ch -
SOUND EFFECT	Sound Effect	SOUND DUAL	Dual
REPEAT	Repeat	REPEAT TEXT	Text
BASS BLAST	Bass Blast	AD SUBT	Subt
TUNING -	I<< / Tuning-	I<<	I<<
PLAY	Play	PLAY MODE ▶	Play
PAUSE	Pause	II	Pause
TUNING +	>>I / Tuning+	>>I	>>I
(i)	(i)	DISPLAY INFO	Info
SLEEP	Sleep	PROG SLEEP	Sleep

Original		Substitut	
RDS/SET	RDS/ Set	SETTINGS OPT	Options
CLOCK	Clock	TIMER AV	AV
ALARM	Alarm	ECO 3D	3D
PTY	PTY	SEARCH TV/R	TV/ R