Original		Substitut	
Standby/On	STANDBY/ON	Power	
Mute	MUTE	Mute / Dimmer	DIMMER MUTE
Play		Play / Slow	SLOW
Pause		Pause / Step / Freeze	STEP-FREEZE
Stop		Stop / Hold	HOLD
<<I / I<<		<< / Tune-	TUNE-
II>>I / >>		>> / Tune+	TUNE+
I<<		I<< / Preset-	PRESET-
>>I		>>I / Preset+	PRESET+
Sound	DIALOGUE SOUND	Sound / Title	TITLE SOUND
Audio	PROGRAM AUDIO	Audio / Lang I/II	LANG I/II AUDIO
Subtitle	REPEAT SUBTITLE	Subtitle / EQ	EQ SUBTITLE
Open/Close	OPEN/CLOSE	Eject / Surround	SURROUND
Front Surround	FRONT SURROUND	Picture / Format	FORMAT PICTURE
Zoom	ZOOM 1	Zoom / Size	SIZE ZOOM
Quiet/Midnight	QUIET/ MIDNIGHT ENTER	Sleep / Timer	TIMER SLEEP
Program	PROGRAM AUDIO	TV/Radio / Program	PROGRAM TV/ RADIO

Original		Substitut	
DVD Menu	DVD MENU	D.Menu / Top	TOP MENU D.MENU
System Setup	SYSTEM SETUP 7	Setup / OPT /	OPT-TOOLS SETUP
Dialogue	DIALOGUE SOUND	Text / Goto	GOTO TEXT
Input Tv Control	INPUT	AV / Input / RDS	RDS AV INPUT
Home Menu	HOME MENU	Menu / Home	HOME MENU
Up/Tune+	TUNE+	Up	
Angle	RANDOM ANGLE	Info / Angle	ANGLE INFO
Left/ST-	ST-	Left	
Enter	ENTER	OK	OK
Right/ST+	ST+	Right	
CLR	SURROUND CLR	Exit / Cancel / Clear	CLEAR EXIT CANCEL
Down/Tune-	TUNE-	Down	
Return	RETURN	Back / Return	RETURN BACK
Volume	MASTER VOLUME +	Vol +	VOL
CH Level	CH LEVEL 9	Smart / List	LIST SMART
CH+ Tv Control	CH	CH+ / Page+	CH PAGE
Volume Master-	MASTER VOLUME -	Vol -	VOL

Original		Substitut	
DISPLAY 3	Display	MEDIA DISPLAY	Display / Media
CH	CH+ Tv Control	CH PAGE	CH+ / Page-
ZOOM 1	1	TV 1	1
TOP MENU 2	2	DVD 2	2
DISPLAY 3	3	CD - STB 3	3
DIMMER 4	4	VIDEO 4	4
5	5	TAPE 5	5
TIMER/ CLOCK 6	6	TUNER 6	6
SYSTEM SETUP 7	7	AUX - HDD 7	7
TEST TONE 8	8	USB 8	8
CH LEVEL 9	9	BLUETOOTH 9	9
ADVANCED 0	0	HDMI - SAT 0	0
REPEAT SUBTITLE	Repeat	APP REPEAT	Green / APP / Repeat
RANDOM ANGLE	Random	Prime Video RANDOM	Blue / Prime Video / Random
	Power Tv Control	SHIFT +	Shift + Power
DIMMER 4	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
TEST TONE 8	Test Tone	SHIFT + TITLE SOUND	Shift + Sound / Title

Original		Substitut	
BASS MODE	Bass Mode	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II
SURROUND CLR	Surround	SHIFT + SURROUND	Shift + Eject / Surround
TIMER/ CLOCK 6	Timer/Clock	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
TV	TV	SHIFT + PROGRAM TV/ RADIO	Shift + TV/Radio / Program
TOP MENU 2	Top Menu	SHIFT + TOP MENU D.MENU	Shift + D.Menu / Top Menu
ADVANCED 0	Advanced	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
+ VOL	Vol + Tv Control	SHIFT + + VOL	Shift + Vol +
VOL -	Vol - Tv Control	SHIFT + VOL -	Shift + Vol -
L1/L2 LINE	Line/L1/L2	SHIFT + TV 1	Shift + 1
CD DVD	DVD/CD	SHIFT + DVD 2	Shift + 2
FM/AM TUNER	Tuner/FM/AM	SHIFT + TUNER 6	Shift + 6