Mandis shop

# Sony RM-SC30

| Original | | Substitut | |
|---|---|---|---|
| | Power | | Power |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| DISPLAY | Display | DISPLAY INFO | Info |
| SELECT | Select | -/-- GUIDE | Guide |
| SET | Set Clock/Timer | FAV PRE-CH | Pre Ch |
| TUNER MEMORY | Tuner Memory | REC MODE | Rec |
| AUDIO IN | Audio In | A | Red |
| PLAY MODE/ TUNING MODE | Play Mode/Tuning Mode | SHIFT + PLAY MODE | Shift + Play |
| CD | CD | C | Yellow |
| REPEAT/ FM MODE | Repeat/FM | REPEAT TEXT | Text |
| TUNER BAND | Band/Tuner | B | Green |
| FUNCTION | Function | TOP MENU MENU | Menu |
| | I<< | | I<< |
| | >>I | | >>I |
| | << | | << |
| | >> | | >> |
| | Play | PLAY MODE | Play |

| Original | | Substitut | |
|---|---|---|---|
| | Pause | | Pause |
| | Stop | | Stop |
| ENTER | Enter | OK | Ok |
| VOLUME | Vol+ | VOL + | Vol + |
| VOLUME | Vol- | VOL – | Vol - |
| | Folder + | CH + | Ch + |
| | Folder - | CH – | Ch - |
| CLEAR | Clear | CLEAR EXIT | Exit |
| EQ | EQ | SETTINGS OPT | Options |

https://mandos-a-distancia.es/ca/Sony/1062939-6157-comandament-de-substitucio-per-Sony-RM-SC-31-A1237274A.html