Original		Substitut	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
▶	Play	SLOW ▶	Play / Slow
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
⏮	I<<	PRESET- ⏮	I<< / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
3D SOUND	3D Sound	TITLE SOUND	Sound / Title
DOLBY PL II	Dolby PL II	LANG I/II AUDIO	Audio / Lang I/II
S/W LEVEL	S/W Level	EQ SUBTITLE	Subtitle / EQ
⏏	Eject	SURROUND ⏏	Eject / Surround
FULL SCREEN	Full Screen	SIZE ZOOM	Zoom / Size
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
FUNCTION TV SOURCE	Function	PROGRAM TV/RADIO	TV/Radio /
DISC MENU	Disc Menu	TOP MENU D.MENU	D.Menu / Top Menu

Original		Substitut	
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
vTuner	vTuner	GOTO TEXT	Text / Goto
MENU	Menu	HOME MENU	Menu / Home
▲	Up	▲	Up
INFO i	Info	ANGLE INFO	Info / Angle
◀	Left	◀	Left
⏎	Enter	OK	OK
▶	Right	▶	Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
▼	Down	▼	Down
RETURN	Return	RETURN BACK	Back / Return
VOL +	Vol +	VOL +	Vol +
SMART HUB	Smart Hub	LIST SMART	Smart / List
TUNING / CH +	Tuning / CH +	CH PAGE +	CH+ / Page+
VOL −	Vol -	VOL −	Vol -
DSP	DSP	MEDIA DISPLAY	Display / Media
TUNING / CH −	Tuning / CH -	CH PAGE −	CH- / Page-

Original		Substitut	
RDS DISPLAY 1	1 / RDS Displa	TV 1	1
2	2	DVD 2	2
TA 3	3 / TA	CD - STB 3	3
PTY- 4	4 / PTY -	VIDEO 4	4
PTY SEARCH 5	5 / PTY Search	TAPE 5	5
PTY+ 6	6 / PTY +	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
SFE MODE	SFE Mode	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
2D→3D	2D → 3D	PC FAV MARKER	Fav / Marker / PC
A	Red	NETFLIX SEARCH	Red / Netflix / Search
iPod SYNC B	Green / iPod Syn	APP REPEAT	Green / APP / Repeat
TUNER MEMORY C	Yellow / Tuner Memory	YouTube REPEAT A-B	Yellow / YouTube / Repeat
MO/ST D	Blue / Mo/St	Prime Video RANDOM	Blue / Prime Video / Random
TITLE MENU POPUP	Title Menu / PopUp Menu	SHIFT + HOME MENU	Shift + Menu / Home

Original		Substitut	
SEARCH	Search	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /

Original		Substitut	
POWER	Power		Power
FUNCTION TV SOURCE	TV Source	RDS AV INPUT	AV / Input / RDS
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
RDS DISPLAY 1	1	TV 1	1
2	2	DVD 2	2
TA 3	3	CD-STB 3	3
PTY- 4	4	VIDEO 4	4
PTY SEARCH 5	5	TAPE 5	5
PTY+ 6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
I<<	I<< / Preset-	PRESET-	
>>I	>>I / Preset+	PRESET+	
<<	<< / Tune-	TUNE-	
>>	>> / Tune+	TUNE+	

Original		Substitut	
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
VOL +	Vol +	VOL +	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
TUNING / CH	CH+	CH PAGE +	CH+ / Page+
VOL -	Vol -	VOL -	Vol -
TUNING / CH	CH-	CH PAGE -	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
INFO	Info	ANGLE INFO	Info / Angle
	Left		Left
	Enter	OK	OK
	Right		Right
RETURN	Return	RETURN BACK	Back / Return
	Down		Down

Original		Substitut		Original		Substitut	
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
A	Red	NETFLIX SEARCH	Red / Netflix / Search				
iPod SYNC B	Green/iPod	APP REPEAT	Green / APP / Repeat				
TUNER MEMORY C	Yellow/Tuner	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
MO/ST D	Blue/Mb/St	Prime Video RANDOM	Blue / Prime Video / Random				
SMART HUB	Smart HUB	LIST SMART	Smart / List				
SEARCH	Search	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /				
2D→3D	2D-3D	LANG I/II AUDIO	Audio / Lang I/II				