Original		Substitut	
POWER	Power		Power
CBL/SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
DVD	DVD	SHIFT + DVD 2	Shift + 2
TV AUDIO	Tv Audio	SHIFT + TV 1	Shift + 1
Blu-ray	Bluray	SHIFT + VIDEO 4	Shift + 4
AUX1	AUX1	SHIFT + AUX - HDD 7	Shift + 7
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
GAME	Game	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
AUX2	AUX2	SHIFT + BLUETOOTH 9	Shift + 9
PHONO	Phono	MEDIA DISPLAY	Display / Media
iPod/USB	iPod/USB	SHIFT + USB 8	Shift + 8
MEDIA PLAYER	Media Player	SHIFT + TAPE 5	Shift + 5
CD	CD	SHIFT + CD - STB 3	Shift + 3
NETWORK	Network	-/-- GUIDE EPG	Guide / EPG / -/--
INTERNET RADIO	Internet Radio	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
1	Favorite Station	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
2	Favorite Station	SHIFT + APP REPEAT	Shift + Green / APP / Repeat

Original		Substitut	
3	Favorite Station	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
4	Favorite Station	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
CH/PAGE	CH/Page+	+ CH PAGE	CH+ / Page+
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOLUME	Vol +	+ VOL	Vol +
CH/PAGE	CH/Page-	CH PAGE –	CH- / Page-
InstaPrevue	InstaPrevue	LIST SMART	Smart / List
VOLUME	Vol -	VOL –	Vol -
INFO	Info	ANGLE INFO	Info / Angle
	Up		Up
OPTION	Option	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT / Tools

Original		Substitut	
TUNE –	I <<< / Tune-	PRESET-	I << / Preset-
TUNE –	I <<< / Tune-	SHIFT + TUNE-	Shift + << /
▶	Play	SLOW ▶	Play / Slow
TUNE +	>>I / Tune+	SHIFT + TUNE+	Shift + >> /
TUNE +	>>I / Tune+	PRESET+	>>I / Preset+
<<	<<	TUNE-	<< / Tune-
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
>>	>>	TUNE+	>> / Tune+
MOVIE	Green/Movie	APP REPEAT	Green / APP / Repeat
MUSIC	Red/Music	NETFLIX SEARCH	Red / Netflix / Search
GAME	Blue/Game	Prime Video RANDOM	Blue / Prime Video / Random
PURE	Yellow/Pure	YouTube REPEAT A-B	Yellow / YouTube / Repeat
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer

Original		Substitut	
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
ENTER	Enter 2	PC FAV MARKER	Fav / Marker / PC

Original		Substitut	
POWER	Power		Power
CBL/SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
DVD	DVD	SHIFT + DVD 2	Shift + 2
TV AUDIO	Tv Audio	SHIFT + TV 1	Shift + 1
Blu-ray	Bluray	SHIFT + VIDEO 4	Shift + 4
AUX1	AUX1	SHIFT + AUX - HDD 7	Shift + 7
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
GAME	Game	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
AUX2	AUX2	SHIFT + BLUETOOTH 9	Shift + 9
PHONO	Phono	MEDIA DISPLAY	Display / Media
iPod/USB	iPod/USB	SHIFT + USB 8	Shift + 8
MEDIA PLAYER	Media Player	SHIFT + TAPE 5	Shift + 5
CD	CD	SHIFT + CD - STB 3	Shift + 3
NETWORK	Network	-/-- GUIDE EPG	Guide / EPG / -/--
INTERNET RADIO	Internet Radio	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
1	Favorite Station	NETFLIX SEARCH	Red / Netflix / Search
2	Favorite Station	APP REPEAT	Green / APP / Repeat

Original		Substitut	
3	Favorite Station	YouTube REPEAT A-B	Yellow / YouTube / Repeat
4	Favorite Station	Prime Video RANDOM	Blue / Prime Video / Random
CH/PAGE	CH/Page+	+ CH PAGE	CH+ / Page+
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOLUME	Vol +	+ VOL	Vol +
CH/PAGE	CH/Page-	CH PAGE –	CH- / Page-
VOLUME	Vol -	VOL –	Vol -
▲	Up	▲	Up
◄	Left	◄	Left
ENTER	Enter	OK	OK
►	Right	►	Right
BACK	Back	RETURN BACK	Back / Return
▼	Down	▼	Down
TUNE –	I <<</ Tune-	SHIFT + TUNE-	Shift + << /
TUNE –	I <<</ Tune-	PRESET-	I << / Preset-
►	Play	SLOW ►	Play / Slow
TUNE +	>>I / Tune+	SHIFT + TUNE+	Shift + >> / Tune+

Original		Substitut		Original		Substitut	
TUNE +	>>I / Tune+	PRESET+	>>I / Preset +				
	<<	TUNE-	<< / Tune-				
	Pause	STEP-FREEZE	Pause / Step / Freeze				
	Stop	HOLD	Stop / Hold				
	>>	TUNE+	>> / Tune+				
1	1	TV 1	1				
2	2	DVD 2	2				
3	3	CD-STB 3	3				
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer				
4	4	VIDEO 4	4				
5	5	TAPE 5	5				
6	6	TUNER 6	6				
7	7	AUX-HDD 7	7				
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				
0	0	HDMI-SAT 0	0				
ENTER	Enter 2	PC FAV MARKER	Fav / Marker / PC				

Original		Substitut	
POWER	Power		Power
CBL/SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
DVD	DVD	SHIFT + DVD 2	Shift + 2
TV AUDIO	Tv Audio	SHIFT + TV 1	Shift + 1
Blu-ray	Blu-ray	SHIFT + VIDEO 4	Shift + 4
AUX1	AUX1	SHIFT + AUX - HDD 7	Shift + 7
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
GAME	Game	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
AUX2	AUX2	SHIFT + BLUETOOTH 9	Shift + 9
PHONO	Phono	MEDIA DISPLAY	Display / Media
iPod/USB	iPod/USB	SHIFT + USB 8	Shift + 8
MEDIA PLAYER	Media Player	SHIFT + TAPE 5	Shift + 5
CD	CD	SHIFT + CD - STB 3	Shift + 3
NETWORK	Network	-/-- GUIDE EPG	Guide / EPG / -/--
INTERNET RADIO	Internet Radio	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
1	Favorite Station	NETFLIX SEARCH	Red / Netflix / Search
2	Favorite Station	APP REPEAT	Green / APP / Repeat

Original		Substitut	
3	Favorite Station	YouTube REPEAT A-B	Yellow / YouTube / Repeat
4	Favorite Station	Prime Video RANDOM	Blue / Prime Video / Random
CH/PAGE	CH/Page+	+ CH PAGE	CH+ / Page+
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOLUME	Vol +	+ VOL	Vol +
CH/PAGE	CH/Page-	CH PAGE –	CH- / Page-
VOLUME	Vol -	VOL –	Vol -
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
TUNE –	I<<</Tune-	SHIFT + TUNE-	Shift + << /
TUNE –	I<<</Tune-	PRESET-	I<< / Preset-
	Play	SLOW	Play / Slow
TUNE +	>>I/Tune+	SHIFT + TUNE+	Shift + >> / Tune+

Original		Substitut		Original		Substitut	
TUNE +	>>I / Tune+	PRESET+	>>I / Preset +				
	<<	TUNE-	<< / Tune-				
	Pause	STEP-FREEZE	Pause / Step / Freeze				
	Stop	HOLD	Stop / Hold				
	>>	TUNE+	>> / Tune+				
1	1	TV 1	1				
2	2	DVD 2	2				
3	3	CD-STB 3	3				
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer				
4	4	VIDEO 4	4				
5	5	TAPE 5	5				
6	6	TUNER 6	6				
7	7	AUX-HDD 7	7				
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				
0	0	HDMI-SAT 0	0				
ENTER	Enter 2	PC FAV MARKER	Fav / Marker / PC				

Original		Substitut		Original	Substitut
POWER	Power		Power		
CBL/SAT	CBL/SAT	HDMI - SAT 0	0		
DVD	DVD	DVD 2	2		
TV AUDIO	Tv Audio	TV 1	1		
Blu-ray	Blu-ray	VIDEO 4	4		
AUX1	AUX1	AUX - HDD 7	7		
GAME	Game	PC FAV MARKER	Fav / Marker / PC		
AUX2	AUX2	BLUETOOTH 9	9		
MEDIA PLAYER	Media Player	TAPE 5	5		
CD	CD	CD - STB 3	3		
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer		