Original		Substitut	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	<<[≡o]	TUNE-	<< / Tune-
	>>/[≡?]	TUNE+	>> / Tune+
	I<<[≡+]	PRESET-	I<< / Preset-
	>>I/[≡..]	PRESET+	>>I / Preset+
	Play	SLOW	Play / Slow
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
	[≡i]	MEDIA DISPLAY	Display / Media
TEXT	Text	GOTO TEXT	Text / Goto
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
FREEZE	Freeze	SHIFT + STEP - FREEZE	Shift + Pause / Step / Freeze

Original		Substitut	
INFO	Info	ANGLE INFO	Info / Angle
MENU	Menu	HOME MENU	Menu / Home
	Source	RDS AV INPUT	AV / Input / RDS
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	OK
+ VOL	Vol+	+ VOL	Vol+
VOL –	Vol-	VOL –	Vol-
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
REC	Rec	REC MODE	Rec / Rec Mode
+ CH	CH+	+ CH PAGE	CH+ / Page+
CH –	CH-	CH PAGE –	CH- / Page-
1	1	TV 1	1

Original		Substitut		Original	Substitut
2	2	2	2		
3	3	3	3		
4	4	4	4		
5	5	5	5		
6	6	6	6		
7	7	7	7		
8	8	8	8		
9	9	9	9		
0	0	0	0		
AUDIO	Audio	AUDIO	Audio / Lang I/II		
RECALL	Recall	BACK	Back / Return		