Mandis shop

JVC RMSUXG6R

Original	Substitut	Original	Substitut
Open/Close	Eject / Surround	Cancel	Exit / Cancel / Clear
Dimmer	Mute / Dimmer	Left	Left
Power	Power	Set	OK
Active Bass EX.	Subtitle / EQ	Right	Right
Clock/Timer	Shift + Sleep / Timer	Play/Pause MD	Pause / Step / Freeze
Sleep	Sleep / Timer	Down	Down
Bass	Sound / Title	AUX	7
Treble	Audio / Lang I/II	<> Tape	>> / Tune+
FM Mode	CH+ / Page+	FM/AM	6
Play Mode	Menu / Home	Play/Pause CD	Play / Slow
Repeat	Green / APP / Repeat	I<<	I<< / Preset-
Auto Preset	CH- / Page-	Stop	Stop / Hold
PTY/EON	Back / Return	>>I	>>I / Preset+
Title/Edit	Info / Angle	Volume+	Vol+
Enter	Smart / List	Volume-	Vol-
Display/Chara.	Display / Media		
Up	Up		

https://mandos-a-distancia.es/ca/JVC/1065394-12352-comandament-de-substitucio-per-JVC-RMSUXG6R.html