Original		Substitut	
	Power		Power
	Caption	EQ SUBTITLE	Subtitle / EQ
	AV Mode	GOTO TEXT	Text / Goto
	[ ]/Ratio	MEDIA DISPLAY	Display / Media
	Input	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
LIST	List	SHIFT + LIST SMART	Shift + Smart / List
0	0	HDMI-SAT 0	0
FLASHBK	Flashbk	SIZE ZOOM	Zoom / Size

Original		Substitut	
VOL	Vol +	VOL	Vol +
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
CH	CH+	CH PAGE	CH+ / Page+
VOL	Vol -	VOL	Vol -
INFO	Info	ANGLE INFO	Info / Angle
CH	CH-	CH PAGE	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
SETTINGS	Settings	OPT-TOOLS SETUP	Setup / OPT /
SMART	Smart	LIST SMART	Smart / List
MY APPS	My APPS	SHIFT + APP REPEAT	Shift + Green / APP /
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
BACK	Back	RETURN BACK	Back / Return
Q.MENU	Q. Menu	TOP MENU D.MENU	D. Menu / Top Menu

Original		Substitut		Original		Substitut	
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
	Red	NETFLIX SEARCH	Red / Netflix / Search				
	Green	APP REPEAT	Green / APP / Repeat				
	yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
	Blue	Prime Video RANDOM	Blue / Prime Video / Random				
	Stop	HOLD	Stop / Hold				
	Play	SLOW	Play / Slow				
	Pause	STEP - FREEZE	Pause / Step / Freeze				
	<<	TUNE-	<< / Tune-				
	>>	TUNE+	>> / Tune+				
	Simplink	FORMAT PICTURE	Picture / Format				
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer				
VD/*	VD/*	SURROUND	Eject / Surround				
TV	TV	PROGRAM TV/ RADIO	TV/Radio /				