Original		Substitut	
	Power		Power
	Tv/ Radi o	PROGRAM TV/ RADIO	TV/ Radi o /
SUBTITLE Q.MENU	Q. Menu/ Subti tl e	HOME MENU	Menu / Home
GUIDE	Gui de	-/-- GUIDE EPG	Gui de / EPG / -/--
AD	AD	LANG I/II AUDIO	Audi o / Lang I/II
INPUT	I nput	RDS AV INPUT	AV / I nput / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
LIST	Li st	SHIFT + LIST SMART	Shi ft + Smart / List
0	0	HDMI - SAT 0	0

Original		Substitut	
Q.VIEW	Q. Vi ew	TOP MENU D.MENU	D. Menu / Top
	Vol +	+ VOL	Vol +
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
P PAGE	P+	+ CH PAGE	CH+ / Page+
	Vol -	VOL −	Vol -
INFO	I nf o	ANGLE INFO	I nf o / Angl e
P PAGE	P-	CH PAGE −	CH- / Page-
MUTE	Mut e	DIMMER MUTE	Mut e / Di mmer
SETTINGS	Set ti ngs	OPT-TOOLS SETUP	Set up / OPT /
SMART	Smart	LIST SMART	Smart / Li st
MY APPS	My APPS	MEDIA DISPLAY	Di spl ay / Medi a
TEXT	Text	GOTO TEXT	Text / Got o
	Up		Up
T.OPT	T. Opt	SHIFT + OPT-TOOLS SETUP	Shi ft + Set up / OPT / Tool s
	Left		Left
OK	OK	OK	OK
	Ri ght		Ri ght

Original		Substitut		Original	Substitut
BACK	Back	RETURN BACK	Back / Return		
	Down		Down		
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
APP/*	APP/*	SHIFT + APP REPEAT	Shift + Green / APP /		
REC/*	Rec/*	REC MODE	Rec / Rec Mode		
LIVE TV	Stop/Line Tv	HOLD	Stop / Hold		
	<<	TUNE-	<< / Tune-		
	Play	SLOW	Play / Slow		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
	>>	TUNE+	>> / Tune+		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		