Mandis shop

AVERMEDIA RM-NG

Original	Substitut	Original	Substitut
Power	Power	>>	>> / Tune+
Mode	D. Menu / Top	I < / Page-	I << / Preset-
Menu	Menu / Home	I > / Slow	Shift + Play /
Up	Up	>I / Page+	>>I / Preset+
Info	Info / Angle	*/Quality	Smart / List
Left	Left	Disk Info	Display / Media
OK	OK	Delete	Exit / Cancel / Clear
Right	Right	F1	1
Recall	Fav / Marker / PC	F2	2
Down	Down	F3	3
Back	Back / Return		
Rec	Rec / Rec Mode		
Photo	Picture / Format		
Play	Play / Slow		
Pause	Pause / Step / Freeze		
<<	<< / Tune-		
Stop	Stop / Hold		

https://mandis-distance.es/ca/AVERMEDIA/1682-9016-comment-de-substituci-per-AVERMEDIA-RM-NG.html