Original		Substitut	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/--	-/--	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
0	0	HDMI - SAT 0	0
	Recall	RETURN BACK	Back / Return
VOL+	Vol +	+ VOL	Vol +
ASPECT	Aspect	SHIFT + FORMAT PICTURE	Shift + Picture / Format
NICAM	Nicam	LANG I/II AUDIO	Audio / Lang I/II

Original		Substitut	
CH+	CH +	+ CH PAGE	CH+ / Page+
VOL-	Vol -	VOL −	Vol -
INPUT	Input	RDS AV INPUT	AV / Input / RDS
CH-	CH -	CH PAGE −	CH- / Page-
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
MENU	Menu	HOME MENU	Menu / Home
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
DISPLAY	Display	MEDIA DISPLAY	Display / Media
PMODE	PMode	FORMAT PICTURE	Picture / Format
SMODE	S. Mode	TITLE SOUND	Sound / Title
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
FAV-	FAV -	SHIFT +	Shift + Down

Original		Substitut		Original		Substitut	
FAV+	FAV +	SHIFT + ▲	Shift + Up	MEDIA	Media	SHIFT + MEDIA DISPLAY	Shift + Display / Media
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--	TV/RADIO	Red / TV/Radio	PROGRAM TV/RADIO	TV/Radio /
TEXT	Text	GOTO TEXT	Text / Goto	TV/RADIO	Red / TV/Radio	NETFLIX SEARCH	Red / Netflix / Search
HOLD	Hold	SHIFT + HOLD ■	Shift + Stop /		Green	APP REPEAT	Green / APP / Repeat
LANG	Lang	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II		Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		Blue	Prime Video RANDOM	Blue / Prime Video / Random
INDEX/◀◀	Index / <<	TUNE- ◀◀	<< / Tune-				
INDEX/◀◀	Index / <<	ANGLE INFO	Info / Angle				
SIZE/▶▶	Size / >>	TUNE+ ▶▶	>> / Tune+				
SIZE/▶▶	Size / >>	SIZE ZOOM	Zoom / Size				
REVEAL/⏮	Reveal / I<<	PRESET- ⏮	I<< / Preset-				
SUBPAGE/⏭	Subpage / >>I	PRESET+ ⏭	>>I / Preset+				
SUBPAGE/⏭	Subpage / >>I	SURROUND ⏏	Eject / Surround				
REC	Rec	REC MODE ●	Rec / Rec Mode				
▶II	Play / Pause	SLOW ▶	Play / Slow				
▶II	Play / Pause	STEP-FREEZE II	Pause / Step / Freeze				
■	Stop	HOLD ■	Stop / Hold				