Mandis shop

R- 40A01

Original	Substitut	Original	Substitut
Power	Power	Menu	Menu / Home
1	1	Right / [≡o]	Right
2	2	Vol +	Vol +
3	3	PR+	CH+ / Page+
4	4	Down	Down
5	5	Sleep/ [≡♦]	Sleep / Timer
6	6	Mute	Mute / Dimmer
7	7	Recall / [≡?]	Fav / Marker / PC
8	8	Red/ Skip	Red / Netflix / Search
9	9	Green/ Movie	Green / APP / Repeat
Source/ [≡]	AV / Input / RDS	[≡x]	TV/ Radio /
0	0	Yellow/ Delete	Yellow / YouTube / Repeat
Normal / OK/ [≡i]	OK	Blue/ Mode	Blue / Prime Video / Random
Up	Up	[≡]	Text / Goto
PR-	CH- / Page-		
Vol -	Vol -		
Left / [≡+]	Left		

https://mandis-distance.es/ca/Dewo/16102-375-comment-substituc-per-Dewo-R40A01-48374A01.htm