Mandis shop

Grundig RP10

Original		Substitut	
	Power		Power
CASS	Cass	PC FAV MARKER	Fav / Marker / PC
TIMER	Timer	TIMER SLEEP	Sleep / Timer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
SELECT	Select	OK	OK
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	Down		Down

Original		Substitut	
RECORD	Record	REC MODE	Rec / Rec Mode
	Pause	STEP - FREEZE	Pause / Step / Freeze
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
PREVIOUS	Previous	PRESET-	I<< / Preset-
	Stop	HOLD	Stop / Hold
NEXT	Next	PRESET+	>>I / Preset+
STORE	Store	LIST SMART	Smart / List
ATS	ATS	OPT-TOOLS SETUP	Setup / OPT /
TRACKING	Tracking	MEDIA DISPLAY	Display / Media
SP/LP	SP/LP	RDS AV INPUT	AV / Input / RDS

https://mandisdistance.com/Grundig/1697-336-manual-de-substituciones-Grundig-RP10-75880000.htm