Mandis shop

RC- 1000C

Original		Substitut	
1 LIN	Line 1		Power
NE 2	Line2	DIMMER MUTE	Mute / Dimmer
BALANCED	Balanced	SLOW	Play / Slow
1 TA	Tape1	STEP-FREEZE	Pause / Step / Freeze
PE 2	Tape 2	HOLD	Stop / Hold
PHONO	Phono	REC MODE	Rec / Rec Mode
SOURCE DIRECT ON/OFF	Source Direct On/Off	TUNE-	<< / Tune-

Original	Substitut

https://mandis.es/es/kenwood/1662-362-control-de-substitucion-kenwood-rc-1000c.html