Original		Substitut	
On / Standby		Power	
Display		Info	
Input BD/DVD		Shift + 1	
Input VCR/DVR		Shift + 2	
Input CBL/SAT		Shift + 3	
Input Game		Shift + 4	
Input AUX		Shift + 5	
Input Tuner		Shift + 6	
Input TV/CD		Shift + 7	
Input Port		Shift + 8	
Muting		Mute	
CH +		Ch +	
CH -		Ch -	
Vol +		Vol +	
Vol -		Vol -	
Guide / Top Menu		D. Menu	
Guide / Top Menu		Shift + Menu	

Original		Substitut	
Guide / Top Menu		Guide	
Prev CH / Menu		Menu	
Prev CH / Menu		Pre Ch	
Up		Up	
Left / Playlist/Category		Left	
Enter		Ok	
Right / Playlist/Categor		Right	
Down		Down	
Setup		Options	
Audio		Dual	
Return		Back	
I<<		I<<	
>>I		>>I	
<<		<<	
Play		Play	
>>		>>	
Pause / Play Reverse		Pause	

Original		Substitut	
	Stop		Stop
MOVIE/TV SEARCH	Movie/TV / Searc	A	Red
MOVIE/TV SEARCH	Movie/TV / Searc	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat	B	Green
MUSIC REPEAT	Music / Repeat	REPEAT TEXT	Text
GAME RANDOM	Game / Random	C	Yellow
STEREO PLAY MODE	Stereo / Play	D	Blue
STEREO PLAY MODE	Stereo / Play	SHIFT + PLAY MODE	Shift + Play
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Substitut	
11 0	0	0	0
+10 D.TUN DIMMER	+10 / Dimmer	SHIFT + GUIDE	Shift + Guide
+10 D.TUN DIMMER	D.Tun Tuner	APP MEDIA	Media
12 CLR SLEEP	Clear / Sleep	CLEAR EXIT	Exit
12 CLR SLEEP	Clear / Sleep	PROG SLEEP	Sleep

Original		Substitut	
On/Standby		Power	
Input BD/DVD		SHIFT + 1	Shift + 1
Input VCR/DVR		SHIFT + 2	Shift + 2
Input CBL/SAT		SHIFT + 3	Shift + 3
Input Game		SHIFT + 4	Shift + 4
Input AUX		SHIFT + 5	Shift + 5
Input Tuner		SHIFT + 6	Shift + 6
Input TV/CD		SHIFT + 7	Shift + 7
Input Port		SHIFT + 8	Shift + 8
Muting		MUTE	Mute
Vol +		VOL +	Vol +
Vol -		VOL -	Vol -
On/Standby		SHIFT + Power	Shift + Power
Display BD/DVD		DISPLAY INFO	Info
Guide / Top Menu BD/DVD		SHIFT + TOP MENU MENU	Shift + Menu
Guide / Top Menu BD/DVD		E-MANUAL D.MENU	D. Menu
Guide / Top Menu BD/DVD		GUIDE	Guide

Original		Substitut	
Prev CH / Menu BD/DVD		TOP MENU MENU	Menu
Prev CH / Menu BD/DVD		FAV PRE-CH	Pre Ch
Up BD/DVD			Up
Left / Playlist/Categor			Left
Enter BD/DVD		OK	Ok
Right / Playlist/Categor			Right
Down BD/DVD			Down
Setup BD/DVD		SETTINGS OPT	Options
Audio BD/DVD		SOUND DUAL	Dual
Return BD/DVD		RETURN BACK	Back
I<< BD/DVD			I<<
>>I BD/DVD			>>I
<< BD/DVD			<<
Play BD/DVD		PLAY MODE	Play
>> BD/DVD			>>
Pause BD/DVD			Pause
Stop BD/DVD			Stop

Original		Substitut	
MOVIE/TV SEARCH	Movie/TV / Search BD/DVD	A	Red
MOVIE/TV SEARCH	Movie/TV / Search BD/DVD	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat BD/DVD	B	Green
MUSIC REPEAT	Music / Repeat BD/DVD	REPEAT TEXT	Text
GAME RANDOM	Game / Random BD/DVD	C	Yellow
STEREO PLAY MODE	Stereo / Play Mode BD/DVD	D	Blue
STEREO PLAY MODE	Stereo / Play Mode BD/DVD	SHIFT + PLAY MODE	Shift + Play
1	1 BD/DVD	1	1
2	2 BD/DVD	2	2
3	3 BD/DVD	3	3
4	4 BD/DVD	4	4
5	5 BD/DVD	5	5
6	6 BD/DVD	6	6
7	7 BD/DVD	7	7
8	8 BD/DVD	8	8
9	9 BD/DVD	9	9
11 0	0 BD/DVD	0	0

Original		Substitut	
--/--- 10 +10 D.TUN DIMMER	+10 / Dimmer	SHIFT + -/-- GUIDE	Shift + Guide
12 CLR SLEEP	CLR / Sleep	CLEAR EXIT	Exit
12 CLR SLEEP	CLR / Sleep	PROG SLEEP	Sleep

Original		Substitut	
ON/STANDBY	On / Standby		Power
BD/DVD	Input BD/DVD	SHIFT +	1
VCR/DVR	Input VCR/DVR	SHIFT +	2
CBL/SAT	Input CBL/SAT	SHIFT +	3
GAME	Input Game	SHIFT +	4
AUX	Input Aux	SHIFT +	5
TUNER	Input Tuner	SHIFT +	6
TV/CD	Input TV/CD	SHIFT +	7
PORT	Input Port	SHIFT +	8
MUTING	Muting	MUTE	Mute
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
ON/STANDBY	On / Standby	SHIFT +	Power
DISPLAY	Display TV/CD	DISPLAY INFO	Info
CH DISC	Disc + / Album + TV/CD	CH +	Ch +
ALBUM	Disc - / Album - TV/CD	CH -	Ch -
	Up TV/CD		Up

Original		Substitut	
PLAYLIST /CATEGORY	Left / Playlist/Category		Left
ENTER	Enter TV/CD	OK	Ok
PLAYLIST /CATEGORY	Right / Playlist/Category		Right
	Down TV/CD		Down
SETUP	Setup TV/CD	SETTINGS OPT	Options
AUDIO	Audio TV/CD	SOUND DUAL	Dual
RETURN	Return TV/CD	RETURN BACK	Back
	I<< TV/CD		I<<
	>>I TV/CD		>>I
	<< TV/CD		<<
	>> TV/CD		>>
	Play TV/CD	PLAY MODE	Play
	Pause TV/CD		Pause
	Stop TV/CD		Stop
MOVIE/TV SEARCH	Movie/TV / Search TV/CD	A	Red
MOVIE/TV SEARCH	Movie/TV / Search TV/CD	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat TV/CD	B	Green

Original		Substitut	
MUSIC REPEAT	Music / Repeat TV/CD	REPEAT TEXT	Text
GAME RANDOM	Game / Random	C	Yellow
STEREO PLAY MODE	Stereo / Play Mode TV/CD	D	Blue
STEREO PLAY MODE	Stereo / Play Mode TV/CD	SHIFT + PLAY MODE	Shift + Play
1	1 TV/CD	1	1
2	2 TV/CD	2	2
3	3 TV/CD	3	3
4	4 TV/CD	4	4
5	5 TV/CD	5	5
6	6 TV/CD	6	6
7	7 TV/CD	7	7
8	8 TV/CD	8	8
9	9 TV/CD	9	9
11 0	0 TV/CD	0	0
10 +10 D.TUN DIMMER	+10 / Dimmer	-/-- GUIDE	Guide
12 CLR SLEEP	CLR / Sleep TV/C	CLEAR EXIT	Exit
12 CLR SLEEP	CLR / Sleep TV/C	PROG SLEEP	Sleep

Original	Substitut

Original		Substitut	
On / Standby		Power	
Input BD/DVD		Shift +	1
Input VCR/DVR		Shift +	2
Input CBL/SAT		Shift +	3
Input Game		Shift +	4
Input AUX		Shift +	5
Input Tuner		Shift +	6
Input TV/CD		Shift +	7
Input Port		Shift +	8
Muting		Mute	
Vol +		Vol +	
Vol -		Vol -	
On / Standby Por		Shift +	Power
Display Port		Info	
CH + Port		Ch +	
CH - Port		Ch -	
Up Port		Up	

Original		Substitut	
Left / Playlist/Categor		Left	
Enter Port		Ok	
Right / Playlist/Categor		Right	
Down Port		Down	
Setup Port		Options	
Return Port		Back	
I<< Port		I<<	
>>I Port		>>I	
<< Port		<<	
Play Port		Play	
>> Port		>>	
Pause / Play Reverse Port		Pause	
Stop Port		Stop	
Movie/TV / Searc Port		Red	
Movie/TV / Searc Port		TV/R	
Music / Repeat		Green	
Music / Repeat		Text	

Original		Substitut	
GAME RANDOM	Game / Random	C	Yellow
STEREO PLAY MODE	Stereo / Play Mode Port	D	Blue
STEREO PLAY MODE	Stereo / Play Mode Port	SHIFT + PLAY MODE	Shift + Play
1	1 Port	1	1
2	2 Port	2	2
3	3 Port	3	3
4	4 Port	4	4
5	5 Port	5	5
6	6 Port	6	6
7	7 Port	7	7
8	8 Port	8	8
9	9 Port	9	9
11 0	0 Port	0	0
10 +10 D.TUN DIMMER	+10 / Dimmer	-/-- GUIDE	Guide
12 CLR SLEEP	CLR / Sleep Port	CLEAR EXIT	Exit
12 CLR SLEEP	CLR / Sleep Port	PROG SLEEP	Sleep

Original	Substitut