Mandis shop

Panasonic N2QAYB000432

Original		Substitut	
	Power		Power
ASPECT	Aspect	ECO 3D	3D
OFF TIMER	Off Timer	PROG SLEEP	Sleep
AUTO SETUP	Auto Setup	HOME SMART	Smart
POS./SIZE	Pos./Size	AD SUBT	Subt
PICTURE	[ ]/Picture	PICTURE FORMAT	Format
SOUND	♪/Sound	SOUND DUAL	Dual
SET UP	Set Up	TOP MENU MENU	Menu
MUTE	Mute	MUTE	Mute
+	Vol+	+ VOL	Vol +
VOL −	Vol-	VOL −	Vol -
N	N	SETTINGS OPT	Options
R	R	REPEAT TEXT	Text
▲	Up	▲	Up
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left

Original		Substitut	
	OK	OK	Ok
INPUT	Input	TIMER AV	AV
RECALL	[+]/Recall	RETURN BACK	Back
MULTI PIP	Multi PIP	APP MEDIA	Media
SWAP	Swap	FAV PRE-CH	Pre Ch
SELECT	Select	-/-- GUIDE	Guide
MOVE ZOOM	Move/Zoom	ZOOM	Eject

https://mandos-a-distancia.es/ca/Panasonic/1055110-84945-comandament-de-substitucio-per-Panasonic-N2QAYB000432.html