Mandis shop

Philips 996510067904

Original		Substitut	
	Power		Power
HDMI ARC	HDMI ARC	1	1
Bluetooth	Bluetooth	3	3
AUX/ AUDIO IN	AUX/Audio In	4	4
USB	USB	2	2
COAX/ OPTICAL	Coax/Optical	5	5
	I<		I<<
	Play	PLAY MODE	Play
	Pause		Pause
	>I		>>I
+ BASS	Bass+		Up
BASS –	Bass-		Down
+ VOLUME	Vol+	+ VOL	Vol +
VOLUME –	Vol-	VOL –	Vol -
+ TREBLE	Treble+	+ CH	Ch +
TREBLE –	Treble-	CH –	Ch -
	Mute	MUTE	Mute

Original		Substitut	
SOUND	Sound	SOUND DUAL	Dual
SURR	Surr	AD SUBT	Subt
DIM	DIM	HOME SMART	Smart
NIGHT MODE	Night Mode	APP MEDIA	Media

https://mandos-a-distancia.es/ca/Philips/1055662-78248-comandament-de-substitucio-per-Philips-Soundstage-996510067904.html