| Original | | Substitut | |
|---|---|---|---|
| | Power | | Power |
| SOURCE | Sourc e | TIMER AV | AV |
| HDMI | HDM | HOME SMART | Smart |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| TTX/MIX | TTX/ M X | REPEAT TEXT | Text |
| PRE-CH | PRE- CH | FAV PRE-CH | Pr e Ch |
| + | Vol + | + VOL | Vol + |
| − | Vol - | VOL − | Vol - |

| Original | | Substitut | |
|---|---|---|---|
| MUTE | Mut e | MUTE | Mut e |
| CH LIST | CH. Li st | DISC NAV LIST | Li st |
| P | P+ | + CH | Ch + |
| P | P- | CH − | Ch - |
| MENU | Menu | TOP MENU MENU | Menu |
| | Smart Hub | APP MEDIA | Medi a |
| GUIDE | Gui de | - / -- GUIDE | Gui de |
| TOOLS | Tool s | SETTINGS OPT | Opt i ons |
| INFO | I nf o | DISPLAY INFO | I nf o |
| RETURN | Ret ur n | RETURN BACK | Back |
| EXIT | Exi t | CLEAR EXIT | Exi t |
| ▲ | Up | ▲ | Up |
| ▼ | Down | ▼ | Down |
| ▶ | Ri ght | ▶ | Ri ght |
| ◀ | Lef t | ◀ | Lef t |
| | Ent er | OK | Ok |
| A | Red | A | Red |

| Original | | Substitut | |
|---|---|---|---|
| B | Green | B | Green |
| C | Yellow | C | Yellow |
| D | Blue | D | Blue |
| Family Story | Family Story | E-MANUAL D.MENU | D. Menu |
| SEARCH | Search | SEARCH TV/R | TV/R |
| DUAL I-II | Dual I-II | SOUND DUAL | Dual |
| SUPPORT | Support | ECO 3D | 3D |
| P.SIZE | P. Size | PICTURE FORMAT | Format |
| AD/SUBT. | AD/Subt | AD SUBT | Subt |
| ◀◀ | << | << | << |
| I◀◀ | I << | I◀◀ | I << |
| ❚❚ | Pause | ❚❚ | Pause |
| ▶▶ | >> | >> | >> |
| ▶▶I | >>I | ▶▶I | >>I |
| ● | Rec | REC MODE ● | Rec |
| ▶ | Play | PLAY MODE ▶ | Play |
| ■ | Stop | ■ | Stop |

| Original | Substitut |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |