Mandis shop

Sharp RRMCG0028SJSA

Original		Substitut	
ON/ STAND-BY	On/Standby		Power
CD	CD	A	Red
VIDEO/AUX	Video/AUX	B	Green
TUNER	Tuner	C	Yellow
BAND	Band	D	Blue
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
	>>I		>>I
	I<<		I<<
VOLUME	Vol+	VOL +	Vol +
VOLUME	Vol-	VOL −	Vol -
PRESET	Preset Up		Up
PRESET	Preset Down		Down
TUN.	>>/Tuner Up		>>
TUN.	<<Tuner Down		<<
OPEN/ CLOSE	Open/Close	ZOOM	Eject

Original		Substitut	
SLEEP	Sleep	PROG SLEEP	Sleep
CLOCK	Clock	HOME SMART	Smart
CLEAR	Clear	CLEAR EXIT	Exit
TIMER	Timer	TIMER AV	AV
RANDOM/ REPEAT	Random/Repeat	REPEAT TEXT	Text
MEMORY	Memory	TOP MENU MENU	Menu
DIMMER	Dimmer	APP MEDIA	Media
SURROUND	Surround	SOUND DUAL	Dual
BASS	Bass Up	+ CH	Ch +
BASS	Bass Down	CH −	Ch -
TREBLE	Treble Down		Left
TREBLE	Treble Up		Right
DISPLAY	Display	DISPLAY INFO	Info
EON	EON	AD SUBT	Subt
PTY. TI	PTY-TI	SEARCH TV/R	TV/R
ASPM	ASPM	ECO 3D	3D

https://mandos-a-distancia.es/ca/Sharp/1063852-2486-comandament-de-substitucio-per-Sharp-RRMCG0028SJSA.html