Mandis shop

Sony RMSD70S

| Original | Substitut | Original | Substitut |
|---|---|---|---|
| Power | Power | Flash | Format |
| Sleep | Sleep | Up | Up |
| Disc Skip | Smart | Down | Down |
| Play CD | Play | Right | Right |
| Pause CD | Pause | Left | Left |
| Stop CD | Stop | On/Off | Ok |
| Play | TV/R | Vol+ | Vol + |
| I<</- Tuner/Band | I<< | Vol- | Vol - |
| >>I/+ | >>I | | |
| Play Deck A | Red | | |
| << Deck A | << | | |
| >> Deck A | >> | | |
| Play Deck B | Green | | |
| Check | Options | | |
| Clear | Exit | | |
| Function | Menu | | |
| Loop | AV | | |

https://mandos-a-distancia.es/ca/Sony/1060741-83073-comandament-de-substitucio-per-Sony-RMSD70S.html