Original		Substitut	
	Power		Power
	Mute	MUTE	Mute
ASPECT	Aspect	PICTURE FORMAT	Format
SOUND	Sound	SHIFT + SOUND DUAL	Shift + Dual
PICTURE	Picture	SHIFT + PICTURE FORMAT	Shift + Format
EPG	EPG	-/-- GUIDE	Guide
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
LIST	List	DISC NAV LIST	List

Original		Substitut	
G	Recall	FAV PRE-CH	Pre Ch
SUB	Sub	AD SUBT	Subt
TEXT	Text	REPEAT TEXT	Text
MIX	Mix	SHIFT + REPEAT TEXT	Shift + Text
SIZE	Size	ZOOM	Eject
HOLD	Hold	SHIFT +	Shift + Stop
REVEAL	Reveal	SETTINGS OPT	Options
SUB.PAGE	Sub.Page	SHIFT + AD SUBT	Shift + Subt
INDEX	Index	SHIFT + DISPLAY INFO	Shift + Info
INFO	Info	DISPLAY INFO	Info
FAV	FAV	SHIFT + FAV PRE-CH	Shift + Pre Ch
MENU	Menu	TOP MENU MENU	Menu
INPUT	Input	TIMER AV	AV
AUDIO	Audio	SOUND DUAL	Dual
	Up		Up
	Right		Right
	Down		Down

Original		Substitut	
	Left		Left
OK	OK	OK	Ok
BACK	Back	RETURN BACK	Back
	Exit	CLEAR EXIT	Exit
+ VOL	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -
SLEEP	Sleep	PROG SLEEP	Sleep
PROG	Prog	SHIFT + PROG SLEEP	Shift + Sleep
+ CH	CH +	+ CH	Ch +
CH –	CH -	CH –	Ch -
	Play / Pause	PLAY MODE ▶	Play
	Play / Pause	❚❚	Pause
	Stop	■	Stop
HDMI SOUR	Source HDMI	APP MEDIA	Media
TV/R	TV / R	SEARCH TV/R	TV/R
DTV	Source DTV	HOME SMART	Smart
	I<<		I<<

Original		Substitut	
	>>I		>>I
	<<		<<
	>>		>>
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue