Original	Substitut	Original	Substitut
Mute	Mute / Dimmer	Yellow / Play	Play / Slow
Power	Power	Yellow / Play	Yellow / YouTube / Repeat
1	1	Blue / >>	>> / Tune+
2	2	Blue / >>	Blue / Prime Video / Random
3	3	Up	Up
4	4	Left	Left
5	5	OK	OK
6	6	Right	Right
7	7	Down	Down
8	8	SFI	D.Menu / Top
9	9	Exit / Recall	Back / Return
✓	Guide / EPG / -/--	Exit / Recall	Exit / Cancel / Clear
0	0	Info	Info / Angle
Red / <<	Red / Netflix / Search	Prog +	CH+ / Page+
Red / <<	<< / Tune-	TV / Radio	TV/Radio /
Green / Stop	Green / APP / Repeat	Vol +	Vol +
Green / Stop	Stop / Hold	Prog -	CH- / Page-

Original		Substitut		Original		Substitut	
MENU	Menu	HOME MENU	Menu / Home				
VOL -	Vol -	VOL -	Vol -				
TV/SAT	TV/SAT	LIST SMART	Smart / List				
TXT	TXT	GOTO TEXT	Text / Goto				
STOP	Stop	STEP-FREEZE II	Pause / Step / Freeze				
EXT	EXT	MEDIA DISPLAY	Display / Media				
SAT1	SAT1 + OK	SHIFT + DVD 2	Shift + 2				
SAT2	SAT2 + OK	SHIFT + CD-STB 3	Shift + 3				
TV	TV + OK	SHIFT + TV 1	Shift + 1				
	PIP	FORMAT PICTURE	Picture / Format				

Original		Substitut	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
✓ -/--	✓	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
A/B	A/B	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
	Red / <<	TUNE-	<< / Tune-
	Red / <<	NETFLIX SEARCH	Red / Netflix / Search
	Green / Stop	APP REPEAT	Green / APP / Repeat

Original		Substitut	
	Green / Stop	HOLD	Stop / Hold
	Yellow / Play	SLOW	Play / Slow
	Yellow / Play	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue / >>	TUNE+	>> / Tune+
	Blue / >>	Prime Video RANDOM	Blue / Prime Video / Random
	Up		Up
	Left		Left
ok	OK	OK	OK
	Right		Right
	Down		Down
SFI	SFI	TOP MENU D.MENU	D.Menu / Top
EXIT	Exit / Recall	CLEAR EXIT CANCEL	Exit / Cancel / Clear
EXIT	Exit / Recall	RETURN BACK	Back / Return
i INFO	Info	ANGLE INFO	Info / Angle
+	Prog +	CH PAGE	CH+ / Page+
TV RADIO	TV / Radio	PROGRAM TV/ RADIO	TV/Radio /
+	Vol +	VOL	Vol +

Original	Substitut	Original	Substitut
Prog -	CH- / Page-		
Menu	Menu / Home		
Vol -	Vol -		
TV/SAT	Smart / List		
TXT	Text / Goto		
Stop	Pause / Step / Freeze		
EXT	Display / Media		
SAT1 + OK	SHIFT + DVD 2 Shift + 2		
SAT2 + OK	SHIFT + CD-STB 3 Shift + 3		
TV + OK	SHIFT + TV 1 Shift + 1		

Original		Substitut	
Mute		Mute / Dimmer	
Power		Power	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
✓		Guide / EPG / -/--	
0		0	
A/B		Shift +	Yellow / YouTube /
Red / <<		Red / Netflix / Search	
Red / <<		<< / Tune-	
Green / Stop		Stop / Hold	

Original		Substitut	
Green / Stop		Green / APP / Repeat	
Yellow / Play		Play / Slow	
Yellow / Play		Yellow / YouTube / Repeat	
Blue / >>		>> / Tune+	
Blue / >>		Blue / Prime Video / Random	
Up		Up	
Left		Left	
OK		OK	
Right		Right	
Down		Down	
SFI		D.Menu / Top	
Exit / Recall		Back / Return	
Exit / Recall		Exit / Cancel / Clear	
Info		Info / Angle	
Prog +		CH+ / Page+	
TV / Radio		TV/Radio /	
Vol +		Vol +	

Original	Substitut	Original	Substitut
Prog -	CH- / Page-		
Menu	Menu / Home		
Vol -	Vol -		
TV/SAT	Smart / List		
TXT	Text / Goto		
Stop	Pause / Step / Freeze		
EXT	Display / Media		
SAT1 + OK	SHIFT + DVD 2 Shift + 2		
SAT2 + OK	SHIFT + CD-STB 3 Shift + 3		
TV + OK	SHIFT + TV 1 Shift + 1		